


**INSTRUCTION MANUAL** 

**Extended Performance** Frequency-to-DC Transmitter

April 2016

Form 165-724-00B



Page 2

# Description

The EP-FDX is a 2-wire, extended performance transmitter that receives input from a turbine or from a positive displacement meter and provides a proportional 4-20mA or 10-50mA output. Input and output parameter range settings are jumper selectable in the field. Stability is provided by a unique quartz-crystal time-base design. RFI/EMI protection, that exceeds SAMA standards, is available as an option. SPAN and ZERO multiturn adjustment is provided. The EP-FDX is available in a variety of housing styles, including: "hockey puck" (HP) and rail-mount (DIN).

## Installation

#### Introduction

This section of the manual provides installation information consisting of mechanical installation, electrical and power connections, and jumper placements.

#### **Mechanical Installation**

Figure 1 illustrates the physical outline of the EP-FDX unit in the DIN housing, Figure 2 shows the hockey puck housing dimensions and physical installation requirements. The units should be installed in a location protected from dust, moisture, and corrosive gas.

#### **Electrical Connections**


All electrical connections are made to the terminals on the front of the unit. Table 1 lists the connector designations. When installing units, use 14-30AWG wire for all signal lines. Terminating lugs are not required for electrical connections. Simply strip the insulation from the end of the wire, tin the end, insert the connector and tighten the screw. To remove a wire, loosen the clamp screw and pull the wire straight out. Remember to tag the wire for proper identification before removing.


Table 1. Terminal Positions


Terminal	Housing		
Designations	DIN	FL/HP	
1	+IN	+IN	
2	-IN	-IN	
3			
4			
. 5	+PS	+PS	
6	-PS	-PS	

#### **Power Connections**

The EP-FDX requires an 11-42 Vdc power supply connected to a +PS and -PS terminals. Table 1 lists the power connector designations for the unit.










Figure 2. Dimensions for the EP-FDX Transmitter Unit with HP Housing.

Important Note: This document is complete as of printing date; however, subsequent product changes may be reflected in companion documents.



## **Calibration**

#### Introduction

This section of the manual provides information needed to calibrate the EP-FDX. Each unit is adjusted and checked at the factory for proper performance before it is shipped.

#### Control Description and Location

ZERO and SPAN controls are located on the front panel of the unit. The SPAN potentiometer adjusts for any span within the jumper-selected range. The ZERO potentiometer provides adjustability about 0 to ±10% of span. The external controls are adjustable with a flat-blade screwdriver. The screwdriver blade must be no more than 0.1 inch (2.54 mm) wide. A wider blade may permanently damage the potentiometer mounting. The potentiometers are equipped with a slip clutch at each end. This prevents damage if the controls are turned beyond the wiper stop. Turning the controls clockwise will result in an increasing output, and turning the controls counter-clockwise will result in a decreasing output.

#### **Test Equipment and Tools**

Test equipment and tools that are needed to calibrate the EP-FDX are shown in Table 2. The listed tools and equipment are not supplied with the unit and must be provided by the user.

#### **Preliminary Procedures**

To change calibration for the values that are preset at the factory, it is necessary to gain access to the programming jumpers. For the DIN-type housing this is accomplished by removing the cover on the side of the unit. For the Hockey-Puck (HP) unit, the four top screws must be removed and the electronics assembly must be extracted from the housing. It is not necessary to dismantle the circuit card assembly any further since all jumpers are accessible at the edges of the two cards.

#### Calibration

Calibration consists of simulating the operative input signal and adjusting the unit to obtain the specified output. The results are tabulated as a convenient correction chart for future measurements when the unit is permanently installed. Before calibrating the EP-FDX, read all of the procedures carefully. Jumpers are installed in each unit prior to shipment. It is important to verify that each operating mode is correct before calibration procedures begin. See figures 9 and 10 for DIN jumper locations and figures 6 and 7 for HP jumper locations.

Table 2. Test Equipment and Tools Required

Equipment or Tool	Characteristic	Purpose
Screwdriver (blade)	Blade not wider than 0.1 inch (2.54 mm)	Front panel control adjustment
AC Signal Source	Must be frequency stable to within ±0.05% or better	Simulates input
DC Voltmeter	Must be accurate to within ±0.05% or better	Output signal monitoring (across series output resistor)
DC Miliammeter	Must be accurate to within ±0.05%	Output signal monitoring
Frequency Counter	Must be capable of measuring output of AC signal source to within 0.05% or better	Measure frequency of AC signal source

# **Specifications**

		T			
Characteristic	es	Common Mode Rejection	54db, minimum, up to 120Hz	Power	<b>12-42DC</b> 12-42VDC
Front Panel Adjustments Performance	Span: Multiturn potentiometer provides full adjustability over the selected input range.  Zero: Multiturn potentiometer provides adjustability about 0 to ±10% of span  Calibration Capability: ±0.05% of span.	- Hejection Output Noise Weight	≤ 10mV, P/P (dc to 10KHz) ≤ 100mV, P/P (above 10KHz) 141.5 grams (5oz), without explosion-proof enclosure, 1.36 kilograms (3lb), ap- proximate, with explosion- proof enclosure	Housings	DIN DIN-style rail-mount housing FL Aluminum case (HP) with mounting flanges for relay-track or surface mounting HP Standard aluminum case with spring clips for mounting in explosion-proof enclosures HPD Aluminum case with clip assembly
	Temperature Effect: ±0.01% of span / °F Loop Load Effect:	Ordering Spe	ecifications		OTH Oil tight, NEMA, 12 enclosure WTH Water tight, NEMA,
·	±0.002% of span for 100 ohm change in loop resistance	Unit	EPFDX		4 enclosure  2HG Explosion-proof, high glass dome, 2 hub
	Line Voltage Effect: ±0.002% of span/volt	Input	Range: see table below		2HS Explosion-proof, 2 hub, solid cover, 2* pipe
	change	Output	Current: 4-20MA 4-20mA		mounting assy. <b>2LS</b> Explosion-proof, 2
Operating Temperature	Range: -29°C to +82°C (-20°F to +180°F)		(30mA limit, maximum) 10-50MA 10-50mA (65mA limit, maximum)		hub, solid cover <b>3HG</b> Explosion-proof, high glass dome, 3 hub
*Input Impedance	10K ohms, ±20% for all units not equipped with the -RF option.	Options	-CC Contact Closure -RF RFI/EMI protection (as defined by SAMA		3HS Explosion-proof, solid cover, 3 hub 3LS Explosion-proof, 3 hub, solid cover
*Input Isolation	500Vrms, for all units not equipped with the -RF option.		standard 33.1) Sensitivity: -S10 10mV, P/P -S30 30mV, P/P		P (suffix) 2' pipe mounting
input Amplitude	10mV P/P to 30V P/P		-S100 100mV, P/P (If no sensitivity option is specified, 300mV P/P is provided as standard)		
* Because RF filte	ring adds shunt capacitance	to each terminal, c	consult the factory for		

performance specifications of units equipped with the -RF option.

When ordering specify:
Unit/Input Range - Input Sensitivity/Output/Power/Options [Housing]

Model number example: EPFDX/A/4-20MA/12-42DC/-CC [HP]

input	Frequency	Range
-------	-----------	-------

Code	Range (Hz)	Code	Range (Hz)	Code	Range (Hz)	Code	Range (Hz)
A B C D E F	3.12 - 4.68 4.68 - 6.25 6.25 - 9.37 9.37 - 12.50 12.50 - 18.75 18.75 - 25.00	GHJKLM	25.00 - 37.50 37.50 - 50.00 50.00 - 75.00 75.00 - 100.00 100.00 - 150.00 150.00 - 200.00	N P Q R S T	200 - 300 300 - 400 400 - 600 600 - 800 800 - 1200 1200 - 1600	U <b>W</b> X	1600 - 2400 2400 - 3200 3200 - 4800 4800 - 6400

The following section of the EP-FDX manual consists of a step-by-step procedural guide for calibrating a unit:

- Connect the EP-FDX to the test equipment with the signal generator temporarily disconnected and the input terminals of the unit short circuited.
- 2 Apply power input to the unit.
- With the input terminals of the unit shorted, adjust the ZERO potentiometer to 4mA.
- Remove the short circuit from the input terminals of the unit and connect the signal generator to these terminals. Adjust the signal generator to the maximum frequency that will be applied to the unit when it is installed, and adjust the output of the signal generator to a value greater than 300 millivolts RMS but not more than 10 volts RMS.
- Adjust the SPAN potentiometer to obtain 100% output with the input applied as above.
- Repeat the above steps until no further adjustment of either the ZERO or SPAN potentiometer is required.
- Successively apply frequencies of 25%, 50%, and 75% of the frequency used in step 4 to the unit and check that the output is linearly proportional (within  $\pm 0.1\%$  of the output span) to the applied frequency.

After step 7 has been successfully completed, remove the signal input to the unit and then turn off the power input to the unit.

#### **Changing Input Range**

The EP-FDX is capable of accepting frequency input from 0-3.12 to 0-6400 Hz in twenty-two different ranges. Changing from one input range to another requires the selection of an appropriate combination of eight solderless jumpers. The following section of the EP-FDX manual consists of a step-by-step procedural guide for changing the input range of a unit:

- The input signal should be a zero crossing signal.
- With no signal applied, the input should have a noise level of less than 1 millivolt, peak to peak.
- Place the EP-FDX transmitter no more than three feet from the signal source.
- 4 Avoid RFI.
- Use twisted, shielded input wire and ground it at the signal end.
- The power supply for the loop current should be low capacity to the ac power line.




Figure 3. Test Equipment Set-Up For Calibration of Unit

- The signal-to-signal noise ratio should be at least 4 to 1 (12dB) at the input.
- Ground the HP case or DIN rail to a water pipe ground.
- Ensure that the electromagnetic pick-up is not located near electromagnetic disturbance.

Refer to Table 4 (EP-FDX Jumper Programming) for the minimum signal necessary to activate the transmitter. The EP-FDX is available in four levels of input sensitivity: -S10 (10mV), -S30 (30mV), -S100 (100mV), and 300 mV p-p, which is supplied (preprogrammed) if an input sensitivity level is not specified. When the Contact Closure (-CC) option is selected, the -S100 sensitivity level option must also be selected.


# Theory Of Operation

#### Introduction

This section of the manual briefly describes the operation of the EP-FDX. A simplified block diagram of the unit is provided to help explain the circuit description. Figure 4 shows the EP-FDX block diagram. Detailed schematics and assembly drawings can be found in figures 5 through 10.

#### Operation

The incoming signal is amplified by a gain-programmable, D.C. coupled preamp and is processed by a level discriminator. An output one-shot multi-vibrator drives the isolating photo-coupler which transfers a digital pulse train at the input signal frequency to the pulse processing section. This section outputs a



pulse of precision height, the width of which is controlled by a jumper-plug-programmable counter. A quartz crystal time base ensures a precise pulse width output for each signal input pulse. This train of pulses is integrated by the active low-pass filter to achieve a voltage output that is proportional to input signal frequency. The output driver converts this control voltage to a 4 to 20 mA loop current. Power for the isolated input section is provided by a transformer-coupled inverter circuit. This, in conjunction with the photo coupler, results in both power and signal isolation.

#### Maintenance

This section of the manual contains maintenance and minor troubleshooting information as well as unit documentation data. The design of the EP-FDX limits maintenance to basically keeping the input and output terminals and conductors clean and tightly fitted to maintain a good heat conduction path to a suitable sink. A complete cleaining of the terminal block requires total disassembly and should be done only at the factory. It is recommended that the user check the termination leads periodically (every six months) to verify that they are tightly fitted and free from oxidation.

#### **Troubleshooting**

Troubleshooting is carried out by tracing the signal with an oscilloscope and referring to the schematic diagrams to determine which component or device might be causing an abnormal indication. If the original problem was a "complete failure of the unit to operate," the component or components that are most likely to be malfunctioning are those associated with the power supply. If the unit is producing an incorrect (but not zero) output, check the outputs from the input circuit and trace the resulting signal through the unit.

Figure 4. Block Diagram



#### Table 4. EP-FDX Jumper Programming

INPUT FREQUENCY RANGE. An input frequency range is selected by the installation of the appropriate jumpers as shown below.
 Jumpers that are not installed are stored on a single unused pin.

CODE	INPUT FREQUENCY RANGE SPAN (Hz)	MINIMUM USABLE FREQUENCY*	JUMPERS USED FOR INPUT	FREQUENCY RANGE SELECTION
			INPUT RANGE	FILTER
A	3.12 - 4.68	0.3	J3, 13, 14, 17, 19	J2, 6, 7
В	4.68 - 6.25	0.3	J4, 13, 14, 17, 19	J2, 6, 7
С	6.25 - 9.37	0.3	J3, 13, 14, 17, 18	J2, 6, 7
D E F	9.37 - 12.50	0.3	J4, 13, 14, 17, 18	J2, 6, 7
E	12.5 - 18.75	0.6	J3, 13, 14, 16, 19	J2, 6, 7
F	18.75 - 25	0.6	J4, 14, 14, 16, 19	J2, 6, 7
G	25 - 37.5	1 .	J3, 13, 14, 16, 18	J2, 6, 7
Н	37.5 - 50	1	J4, 13, 14, 16, 18	J2, 6, 7
J	50 - 75	1	J3, 12, 15, 17, 19	J2, 6, 7
K	75 - 100	. 1	J4, 12, 15, 17, 19	J2, 6, 7
L,	100 - 150	2 2	J3, 12, 15, 17, 18	J6
M	150 - 200		J4, 12, 15, 17, 18	. J6
N	200 - 300	2	J3, 12, 15, 16, 19	<b>J</b> 6
P	300 - 400	2	J4, 12, 15, 16, 19	<b>J</b> 6
Q ·	400 - 600	4	J3, 12, 15, 16, 18	
R	600 - 800	4	J4, 12, 15, 16, 18	
R S T	800 - 1200	8	J3, 12, 14, 17, 19	
Т	1200 - 1600	8	J4, 12, 14, 17, 19	
U	1600 - 2400	16	J3, 12, 14, 17, 18	
V	2400 - 3200	16	J4, 12, 14, 17, 18	
W	3200 - 4800	32	J3, 12, 14, 16, 19	
X	4800 - 6400	32	J4, 12, 14, 16, 19	

\*Output goes to Zero (e.g. 4.0 mA) with no input. These numbers represent minimum useable frequencies with a ripple component of less than 10 mV p-p.

2. INPUT SENSITIVITY (±20%). To implement a specified input sensitivity, one or two of the three input sensitivity jumpers must be installed as shown below.

mV, p-p	JUMPERS
10	J8, 11
30	J8
100	J9, 11
300	J9

OUTPUT RANGE SELECTION is implemented by either the installation or storing of jumpers J1 and 5.

OUTPUT RANGE	JUMPERS
4 to 20 ma.	(jumpers are stored, not used)
10 to 50 ma.	J1, 5

4. CONTACT CLOSURE MODE is implemented by the selection of the following jumpers: J9, 10, 11. (100 mV Input Sensitivity [J9 & 11] must be selected when CONTACT CLOSURE MODE is used.) This mode can be used for Input Ranges A through M only.





Figure 5. Schematic Diagram for the EP-FDX Transmitter with HP Housing

165-424-00








Figure 6. Printed Circuit Board Assembly 1 for the EP-FDX Transmitter with HP Housing






Figure 7. Printed Circuit Board Assembly 2 for the EP-FDX Transmitter with HP Housing






Figure 8. Schematic Diagram for the EP-FDX Transmitter with DIN Housing

165-426-00




Figure 9. Printed Circuit Board Assembly 1 for the EP-FDX Transmitter with DIN Housing






Figure 10. Printed Circuit Board Assembly 2 for the EP-FDX Transmitter with DIN Housing

165-527-00



# **EP-FDX**

Extended Performance Frequency-to-DC Transmitter

#### SUPPLEMENT

To Manual No. 165-724-00 A

September 1992

# **Purpose**

This supplement is intended for users of Moore Industries' EP-FDX. It contains additional information regarding jumper settings, which is not adequately covered in the current Instruction Manual (rev. A).

The information in this supplement will be incorporated in the manual during the next scheduled revision of that document.

#### The Input Coupling Jumper (J21)

The EP-FDX accepts either an ac or a dc type frequency input. To configure the unit to properly process the input, an internal, removable jumper is provided. Installation or removal of jumper J21 configures the unit for the required input type. Table 1s lists the jumper condition for the two input type options.

Table 1s. Input Type Jumper Settings

Input Type	J21 Setting
AC	Store
DC	Install

Figures 1s through 4s show the location of all the available jumpers for both the DIN- and HP-style EP-FDX's.

#### **The Contact Closure Option**

Units configured with the Contact Closure Option (CC) require jumpers J9, J10, J11, and J21 to be installed for the EP-FDX to repond properly to a contact closure input.




Figure 1s. DIN-style PC1 Jumper Locations




Figure 2s. DIN-style PC2 Jumper Locations




Figure 3s. HP-style PC1 Jumper Locations




Figure 4s. HP-style PC2 Jumper Locations

#### RETURN PROCEDURES

#### To return equipment to Moore Industries for repair, follow these four steps:

1. Call Moore Industries and request a Returned Material Authorization (RMA) number.

#### Warranty Repair –

If you are unsure if your unit is still under warranty, we can use the unit's serial number to verify the warranty status for you over the phone. Be sure to include the RMA number on all documentation.

#### Non-Warranty Repair -

If your unit is out of warranty, be prepared to give us a Purchase Order number when you call. In most cases, we will be able to quote you the repair costs at that time. The repair price you are quoted will be a "Not To Exceed" price, which means that the actual repair costs may be less than the quote. Be sure to include the RMA number on all documentation.

- 2. Provide us with the following documentation:
  - a) A note listing the symptoms that indicate the unit needs repair
  - b) Complete shipping information for return of the equipment after repair
  - c) The name and phone number of the person to contact if questions arise at the factory
- Use sufficient packing material and carefully pack the equipment in a sturdy shipping container.
- 4. Ship the equipment to the Moore Industries location nearest you.

The returned equipment will be inspected and tested at the factory. A Moore Industries representative will contact the person designated on your documentation if more information is needed. The repaired equipment, or its replacement, will be returned to you in accordance with the shipping instructions furnished in your documentation.

#### WARRANTY DISCLAIMER

THE COMPANY MAKES NO EXPRESS, IMPLIED OR STATUTORY WARRANTIES (INCLUDING ANY WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE) WITH RESPECT TO ANY GOODS OR SERVICES SOLD BY THE COMPANY. THE COMPANY DISCLAIMS ALL WARRANTIES ARISING FROM ANY COURSE OF DEALING OR TRADE USAGE, AND ANY BUYER OF GOODS OR SERVICES FROM THE COMPANY ACKNOWLEDGES THAT THERE ARE NO WARRANTIES IMPLIED BY CUSTOM OR USAGE IN THE TRADE OF THE BUYER AND OF THE COMPANY, AND THAT ANY PRIOR DEALINGS OF THE BUYER WITH THE COMPANY DO NOT IMPLY THAT THE COMPANY WARRANTS THE GOODS OR SERVICES IN ANY WAY.

ANY BUYER OF GOODS OR SERVICES FROM THE COMPANY AGREES WITH THE COMPANY THAT THE SOLE AND EXCLUSIVE REMEDIES FOR BREACH OF ANY WARRANTY CONCERNING THE GOODS OR SERVICES SHALL BE FOR THE COMPANY, AT ITS OPTION, TO REPAIR OR REPLACE THE GOODS OR SERVICES OR REFUND THE PURCHASE PRICE. THE COMPANY SHALL IN NO EVENT BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES EVEN IF THE COMPANY FAILS IN ANY ATTEMPT TO REMEDY DEFECTS IN THE GOODS OR SERVICES, BUT IN SUCH CASE THE BUYER SHALL BE ENTITLED TO NO MORE THAN A REFUND OF ALL MONIES PAID TO THE COMPANY BY THE BUYER FOR PURCHASE OF THE GOODS OR SERVICES.

ANY CAUSE OF ACTION FOR BREACH OF ANY WARRANTY BY THE COMPANY SHALL BE BARRED UNLESS THE COMPANY RECEIVES FROM THE BUYER A WRITTEN NOTICE OF THE ALLEGED DEFECT OR BREACH WITHIN TEN DAYS FROM THE EARLIEST DATE ON WHICH THE BUYER COULD REASONABLY HAVE DISCOVERED THE ALLEGED DEFECT OR BREACH, AND NO ACTION FOR THE BREACH OF ANY WARRANTY SHALL BE COMMENCED BY THE BUYER ANY LATER THAN TWELVE MONTHS FROM THE EARLIEST DATE ON WHICH THE BUYER COULD REASONABLY HAVE DISCOVERED THE ALLEGED DEFECT OR BREACH

#### RETURN POLICY

For a period of thirty-six (36) months from the date of shipment, and under normal conditions of use and service, Moore Industries ("The Company") will at its option replace, repair or refund the purchase price for any of its manufactured products found, upon return to the Company (transportation charges prepaid and otherwise in accordance with the return procedures established by The Company), to be defective in material or workmanship. This policy extends to the original Buyer only and not to Buyer's customers or the users of Buyer's products, unless Buyer is an engineering contractor in which case the policy shall extend to Buyer's immediate customer only. This policy shall not apply if the product has been subject to alteration, misuse, accident, neglect or improper application, installation, or operation. THE COMPANY SHALL IN NO EVENT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.



WORLDWIDE • www.miinet.com

United States • info@miinet.com Tel: (818) 894-7111 • FAX: (818) 891-2816 Australia • sales@mooreind.com.au Tel: (02) 8536-7200 • FAX: (02) 9525-7296

Tel: 03/448.10.18 • FAX: 03/440.17.97 The Netherlands • sales@mooreind.nl Tel: (0)344-617971 • FAX: (0)344-615920

Belgium • info@mooreind.be

China • sales@mooreind.sh.cn
Tel: 86-21-62491499 • FAX: 86-21-62490635
United Kingdom • sales@mooreind.com
Tel: 01293 514488 • FAX: 01293 536852