MOORE INDUSTRIES WORLDWIDE Demand Moore Reliability

No. 238-722-00J August 2023

-

Smart HART® Humidity and Temperature Transmitter





54.34-

All product names are registered trademarks of their respective companies.

Table of Contents

Introduction	
About This Manual	4
Model and Serial Numbers	4
Inputs	4
Outputs	4
Specifications	5
HDM Dimensions	6
HSM Dimensions	7
Configuring the HTZ	10
Installing the Configuration Software	
Connecting the HTZ to the PC	
Connecting the HTZ to the HART Communicator	
PC Configuration Software Summary	13
Menu and Tool Bar Legend	14
Configuration Screens	14
Input	
Trimming	15
Display	
Analog Outputs (-AO1 and -AO2)	

Using the HART Communicator	19
Programming when a Device Description is Available	19
The HART Communicator Menu With a Device Description	21
The HART Communicator Menu Without a Device Description	24
HART Status Information	26
Installation	30
Mounting	30
Making the Electrical Connections	
Recommended Gound Wiring Practices	
Additional Grounding Information	
CE Conformity	
Operation	30
Maintenance	
Calibration	
Replacing RH Sensor	31
Customer Support	32

Introduction

This is the user's manual for Moore Industries' HTZ Smart HART Humidity and Temperature Transmitter. The HTZ is a loop-powered, HART enabled, transmitter that measures temperature and relative humidity and calculates dew point. The HTZ consists of two specialized components. The Humidity/ Temperature Sensor Module (HSM) has temperature and humidity probes which can easily be removed from the housing for replacement or service. The second component, the Humidity/Temperature Display Module (HDM), can remain connected to output wiring when the sensor assembly (HSM) is removed thus maintaining the output current loops.

The HTZ comes with optional factory trimming (VTB) that offers higher temperature measurement accuracy. It is applied to the sensor module (HSM) and is independent of the display module (HDM).

For ease of viewing, the HSM and HDM may be placed apart from each other using a dedicated 1m (3ft), 3m (10ft), 6m (20ft), 9m (30ft), 15m (49ft), 25m (82ft) or 30m (98ft) (optional) cable utilizing quick disconnect connectors at both ends.

About this Manual

Wherever you see a "<u>Note</u>", "<u>Caution</u>" or "<u>WARNING</u>" pay particular attention.

<u>WARNING</u> - Hazardous procedure or condition that could injure the operator.

<u>Caution</u> - Hazardous procedure or condition that could damage or destroy the unit.

<u>Note</u> - Information that is helpful for a procedure, condition, or operation of the unit.

Model and Serial Numbers

Moore Industries uses a system of model and serial numbers to keep track of all of the information on every unit it sells and services. The HSM and the HDM each have a different, unique serial number. If a problem occurs with your HTZ, check for a tag listing these numbers affixed to the suspect module. Supply the Customer Support representative with this information when calling.

Inputs

The HTZ includes a pre-calibrated relative humidity sensor and a fixed Pt3850 1000 ohm RTD temperature sensor. The temperature sensor's ohms measurement is linearized to temperature.

-FLEX120

The -FLEX120 flexible sensor cable extension option provides a flexible extension for your humidity and temperature sensors. Attached at the sensor connection head, it extends the sensor placement to locations as far as 120 inches (3.48 meters) away. This gives you access to locations where the connection head can't be placed such as hung ceilings, and allows the sensors to be suspended to obtain readings mid-room at lower than ceiling heights. Being flexible, the sensors won't break when bumped during facility changes.

<u>Note</u> - The FLEX120 120-inch flexible sensor extension requires -CL3.75 and -GRIP1 with LH4P housing.

Outputs

Analog Outputs

The HTZ is equipped with two analog outputs (-AO1 and -AO2). Both -AO1 and -AO2 are externally powered (sink only) by 12-42Vdc and output a 4-20mA range with their outputs isolated from each other.

Both are configurable to output current proportional to any of the three available input variables (temperature, relative humidity and dew point).

-A01

This output powers the HTZ. It provides primary loop power for the unit. It may be used without -AO2.

HART communications may only be utilized using -AO1.

-AO2

This output requires its own separate loop power. It may not be used if -AO1 is not in use.

There is no HART communication capability at this output.



Performance Humidity Input Measurement Range: 0-100% RH Calibrated Accuracy*: ±0.75% RH between 33-75% RH; ±1% below 33% RH and above 75% RH (with -VTRH calibration option); Nominal accuracy without -VTRH calibration is ±1.8% between 20-80% RH **Ambient Temperature Effect:** 0.005%/°C Long Term Stability: ±1% RH/year Response Time: 10 seconds to 90% of final value on a step input change @25°C, 1m/s air Temperature Input

Measurement Range: -40°C to +110°C (-40°F to +230°F) Calibrated Accuracy*: ±0.036°C at trim points (with -VTB calibration option); Nominal Accuracy without -VTB calibration is ±0.1°C **Ambient Temperature Effect:** 0.003°C/°C Long Term Stability: 1 year: 0.1°C 3 years: 0.17°C 5 vears: 0.24°C Response Time: 200msec maximum for the output to change from 10% to 90% of its scale for an input step change of 0% to 100%

Dewpoint

Range: -45°C to +100°C (-49°F to +212°F) (calculated from temperature and RH inputs) Accuracy*: Typical @25°C, ±0.5°C between 40-95% RH; ±1-2°C between 10-40% RH **Ambient Temperature Effect:** 0.005°C/°C Long Term Stability: ± 0.5°C RMS over 1 year **Response Time:** 10 seconds to 90% of final value Performance (continued)

Dew Point Calculation: EW * RH / 100 (refer to Equation 1 for explanation) **Analog Output** Output Range: 4-20mA Linear Region: 3.8-21.4mA Hardware Limits: 3.6-23.6mA Accuracy: ±2 microamps Ambient Temperature Effect: 0.009% of span (16mA)/°C Long-Term Stability: 1 year: 0.012% 3 years: 0.020% 5 years: 0.026% Rise Time: 100msec maximum for the output to change from 10% to 90% of its scale for a step change of the sourcing variable of 0% to 100% Damping: User-set between 0-30 seconds Power Supply Requirements: 12-42Vdc at output terminals Power Supply Effect: ±0.002 of span per 1V change Load Effect: Negligible within specified power limits Load Capability: (500 ohms@24V) Supply Voltage - 12V = Ohms 0.024A Ripple: 10mVpp, frequencies up to 120Hz, measured across a 250 ohm load resistor Start up Time: <5sec (trimming disabled) Isolation: 500Vac between each output and between outputs and case Overall Accuracy: Sum of input and output accuracy, ambient temperature effect and long term stability Analog Output Response Time: 500msec from step input until the analog output reaches 90% of its final value **Ambient Conditions Operating Range:**

-40°C to +85°C (-40°F to +185°F)

Smart HART[®] Humidity and Temperature Transmitter

Ambient Conditions (continued) HDM Storage Range: -40°C to +85°C (-40°F to +185°F) HSM Storage Range: Recommended 10-50°C (50-122°F), 20-60%RH; Maximum 0-80°C (32-176°F), 0-95%RH **Humidity Sensor Temperature Limits:** -40°C to +110°C (-40°F to +230°F) Humidity Sensor Maximum Pressure: 125psia **Relative Humidity:** 0-95% relative humidity, non-condensina **RFI/EMI Protection:** 20V/m@80-1000MHz. 1kHz AM. when tested to IEC61000-4-3 Adjustments All adjustments made using Moore Industries' Intelligent PC Configuration Software or HART-enabled hand-held

or host

Indicators

LCD: 2x5 14-segment characters, alphanumeric readout accurate to the nearest digit. Range: -99999 to 99999; Decimal point can be user-set

Weight

HDM: 920g (2lbs) HSM: 600g (1.3lbs) HSM -FLEX: 1.5kg (3.3lbs) Cable: 1m - 82g (3oz) 3m - 196g (7oz) 6m - 368g (13oz) 9m - 1100g (2.4lbs) 15m - 908g (2lbs) 25m - 1100g (2.4lbs) 30m - 1100g. (2.4lbs)

* High accuracy relative humidity measurements are achieved within a RH range of 33-75% using the trimming feature of Moore Industries' Intelligent PC Configuration Software with the RH sensor calibrated against a controlled RH environment (See the -VTRH option under "Sensor Length/Calibration" in Ordering Information). High accuracy temperature measurements are achieved using the trimming feature of the Intelligent PC Configuration Software with the temperature sensor immersed in a temperature calibration bath (Sensor-to-Transmitter matching factory calibration; See the -VTB option under "Sensor Length/Calibration" in Ordering Information). High accuracy dew point measurements are achieved using the trimming feature of the Intelligent PC Configuration Software at 25°C, between 40-90% RH. Stated accuracies do not include ambient temperature effects.

Equation 1. Dew Point Calculation

EW = 10 [^] (0.66077 + (7.5 * T / (237.3 + T)))) This is the saturation vapor pressure over values.	vater
--	--	-------


EW_RH = EW * RH / 100


Multiply EW with RH

Dew Point (Dp)= ((0.66077 - log10 (EW_RH)) * 237.3) / (log10 (EW_RH) - 8.16077)




Figure 1. HDM Dimensions





HTZ Smart HART[®] Humidity and Temperature Transmitter

Figure 3. HSM FLEX120 flexible sensor cable extension option



8




Figure 4. HDM-HSM FLEX120 flexible sensor cable extension option with cable

Configuring the HTZ

One of the benefits of the HTZ is that there are no internal or external controls to adjust or settings to change. All operating parameters are set using Moore Industries' Intelligent PC Configuration software or a HART configurator if using HART communication capabilities (-AO1 only).

Once these software settings are made, they are downloaded to the instrument in the form of a Configuration File and stored in the unit's nonvolatile memory. You can choose to save a backup copy of the file on your PC hard drive or external media. The HTZ communicates with the PC through a proprietary communications cable via the PC's serial (COM) port or using a HART modem cable if HART communications are used.

Installing the Configuration Software

Refer to Table 1 for necessary equipment.

- 1. Download the latest configuration file from the website http://www.miinet.com/
- 2. Or insert the *Moore Industries Interface Solution Configuration Tools* CD into the CD drive of the PC. Access the CD and open the following folders: *Configuration Software and ToolsIHTZ Configuration Tools/HTZ PC Configuration Software.*
- 3. Double-click the installation program located in the folder. Follow the prompts to correctly install the program.

Once the Configuration Program is installed onto your PC, you now have the ability to program the HTZ or while connected, monitor the HTZ's input and output parameters in real time.

No Transmitter Needed

It is not necessary to connect the transmitter to a PC to create configuration files using the software. The Configuration Program can be run without connecting a transmitter, and *most* parameters can be set without the connection of an HTZ.

This makes it easy to create a configuration file offline, save and download them to one or more transmitters at a later time.

The HTZ *must* be connected to the PC in order to: trim input, trim output, assign a tag, perform an output test, receive (via download) a configuration file and save the configuration file from the transmitter's memory.

Connecting the HTZ to the PC

Connect the RS-232 cable to the PC's COM port or Optional USB Cable to the USB port.

Refer to Table 1 for necessary equipment.

Connecting the HTZ to the HART Communicator

Connect the HART Communicator or HART Modem to the HTZ's Analog Output 1 (AO1) as shown in Figure 5.

Device	Specifications
Power Supply	24Vdc, ±10% (One for each analog output (-AO)
Precision Load Resistor	250 ohms, ±0.01% HART specifies that total loop resistance is to be maintained betweer 250 ohms and 1100 ohms (one for each analog output)
Multimeter (optional)	Accurate to ±0.025% of span; e.g., Fluke Model 87
	Microsoft Windows based PC; 16MB free RAM; 20MB free disk space on hard drive
Personal Computer	Microsoft Windows 7, 10 or later
(Required only if using a PC for setup)	1 (one) serial port or one available USB port (with optional USB cable)
Moore Industries Interface Cable	Part Numbers: 803-040-26 (RS232) or Optional USB Cable Part# 804-030-26
HART Modem Cable (Required only if using HART Communication capabilities)	Part Number: 803-048-26, or equivalent Or Optional USB Cable Part# 804-030-26
Moore Industries PC Configuration Software (Required only if using a PC)	Version 1.0 or greater, successfully installed to the hard drive
HART Communicator (Required only if NOT using a PC)	HART Communicator/Calibrator (with HTZ Device Description loaded)

Table 1. Necessary Equipment to Configure the HTZ








Figure 6. HTZ Hook-Up Diagram with AO1 and AO2 Powered



PC Configuration Software Summary

Figure 7. HTZ PC Configuration Software Screen



Once the default configuration has been saved, it is safe to program other parameters. The PC Software is made up of these sections:

1. Menu Bar/Tool Bar– Dropdown menus and corresponding icons allow you to perform various functions throughout the PC Configuration Program. Refer to the *Menu and Tool Bar Legend* for a complete description.

2. Program Status– This portion of the program displays the activity of the connected unit. It will display such messages as: Idle, Monitoring, Uploading and Downloading.

3. HTZ Status– Indicates if there are problems or faults with the instrument.

4. Process Variable– Displays the present Process Variable readings. Available Process Variables include Temperature (Temperature Probe), Relative Humidity and Dew Point.

5. Identification Parameters– Use this parameter to place an identifying *Tag* (8 alphanumeric characters, maximum), *Descriptor* (16 alphanumeric characters, maximum) or *Message* (32 alphanumeric characters, maximum).

Use the *Address* box to change the unit's address (0-15).

To utilize a longer Tag identifier (up to 32 characters, maximum) you may access the *Long Tag* feature located in the *View* dropdown menu. Enter the desired information and click *Set.* To view the Long Tag, click *Read*.

Identification parameters are stored in the HDM.

6. HTZ Device Info- This read-only display indicates serial numbers, firmware versions and hardware versions of both the HSM and HDM. This information is also displayed in the *Device Information* section of the *View* drop down menu.

7. Communications– Notifies user of current PC connection/communications status. The address displayed in the *Address* box must match the address of the unit if HART Communications are being used (Analog Output 1 only).

8. Input/Trimming/Display/Analog Outputs 1 and 2–These tabs change the right side of the screen to allow you to set the appropriate part of the HTZ's configuration. See corresponding sections of this manual for additional information regarding these tabs.

Menu and Tool Bar Legend

File D 🖻 🛢 🎒	Allows such functions as New, Open, Save and Print functions
View	Controls whether Tool and Status Bars are viewed on the screen as well as Additional Status Information, Long Tag and Device Information
Iransfer 🛧 🖶 👓	Allows you to Upload and Download configurations and perform an Address Search
Communications	Allows selection of PC COM ports as well as Communication Method (Auto, RS232 or HART)
Monitoring 🕞 🗖	Allows you to Monitor and Stop monitoring processes
<u>B</u> urst Mode	Allows you to enable Burst Mode
Help	Displays the version of the PC Configuration Program

Configuration Screens

<u>Note:</u>

Unless otherwise noted, ensure that the PC Program is idle before making any selections or configuration changes to the parameters and windows of the program. Also, when attempting to download or upload, monitoring must be stopped. To do this, click "Stop" in the Monitoring dropdown menu, or click the "Stop Monitoring" icon.

Input

Figure 8. Input Tab

ISM Settings Temperature © Deg C © Deg F © Kelvin Filter 50 Hz © 60 Hz © 60 Hz	SensorLimis -40 to 110 Deg C Minimum Span 10 Deg C LowerRange 0
	Upper Range 100
Relative Humidity Range	Dew Point Range
Input Limits 0 to 100 % Minimum Span 10 %	Input Limits -45 to 100 Deg C Minimum Span 10 Deg C
Lower Range 0	Lower Range -40
Upper Range 100	Upper Range 95

HSM Settings– Allows for setting HSM parameters.

Temperature– Selects the unit in which temperature is displayed. This affects the *Sensor Range* limits as well as *Dew Point* ranges on the page.

Filter– This setting is used to configure the input filter. This filter is designed to reduce the effects of mains-induced noise. The input filter frequency value should be set to the frequency of the local AC supply– either 50Hz or 60Hz.

Relative Humidity Range– Permits you to set the lower and upper limits of your allowed relative humidity range.

Enter your desired values in the *Lower* and *Upper Range* text boxes.

Sensor Range– Allows you to set your upper and lower range values within the unit chosen in the *Temperature* section.

Enter your desired values in the *Lower* and *Upper Range* text boxes.

Dew Point Range– Permits you to set the lower and upper limits of your allowed dew point range.

Enter your desired values in the *Lower* and *Upper Range* text boxes.

<u>Note:</u> Once you have configured all parameters, download to the unit by selecting Download in the Transfer drop down menu located in the Status Bar. Or, click the to button in the Tool Bar.

Trimming

Cemperature Trimming		Dew Point Trimming
Disabled	Disabled	Disabled
C 1 Point	C 1 Point	C 1 Point
C 2 Points	C 2 Points	C 2 Points
Point 1	Point 1	Point 1
Set Value	Set Value	Set Value
0	2	-40
Trim		
	Trim	Trim
Trim Value	Trim Value	Trim Value
-0.943008	46.743	-40
Set Value	Set Value	Set Value
100	98	203
Trim	Trim	Trim
Trim Value	Trim Value	Trim Value
100	98	203

Trimming– Trimming increases the measurement accuracy of your instrument by matching the reading of its actual input, to either a calibrated source or the device to which it is connected. This verifies that the input to the transmitter is being interpreted correctly.

You may trim any point between 0% and 100% along the scale. Note that 1 Point trimming applies an offset to the sensor reading, while 2 Point trimming applies both an offset and a gain.

By default all three variable options are disabled. To perform trimming each variable must be enabled (individually). In order to enable each variable, user must place a check mark in front of the variable that requires trimming. This can be done using the Trimming Menu on the Menu/Tool Bar (Refer to Figure 9 for Trimming Menu location). Figure 10. Trimming Enable/Disable Menu



Temperature Trimming– By default this option is disabled. Once enabled, take the following steps to set trim variable (temperature probe) to desired values.

 Select either 1 Point (one-point trimming) or 2 Points (two-point trimming) by clicking the appropriate button. Each pair consists of Set Value and Trim Value fields. The following prompt will appear:

<u>Warning:</u>

- -Please confirm you wish to do this. Changing the trimming mode will reset the trimming values.
- 1. Hit "YES" button to continue or "NO" button to abort.
- 2. Enter the values that require trimming into the *Set Value* field.
- 3. Apply the targeted signal to the input, wait until it settles, and click *Trim* to capture the measured value.
- 4. If you chose *2 Points*, repeat the steps above for the second point.

Relative Humidity Trimming– By default this option is disabled. Once enabled, take the following steps to set trim variable to desired values.

1. Select either *1 Point* (one-point trimming) or *2 Points* (two-point trimming) by clicking the appropriate button. Each pair consists of *Set Value* and *Trim Value* fields. The following prompt will appear:

<u>Warning:</u>

Please confirm you wish to do this. Changing the trimming mode will reset the trimming values. Changing the Relative Humidity will affect the Dew Point.

Hit "YES" button to continue or "NO" button to abort.

2. Enter the values that require trimming into the *Set Value* field.

HTZ Smart HART[®] Humidity and Temperature Transmitter

- 3. Apply the targeted signal to the input, wait until it settles, and click *Trim* to capture the measured value.
- 4. If you chose 2 *Points*, repeat the steps above for the second point.

Note: The Relative Humidity probe has a monolithic chip which produces a Relative Humidity and a temperature measurement. These two measurements are used to calculate the Dew Point. The temperature probe reading is not used in the Dew Point Calculation.

Dew Point Trimming– By default this option is disabled. Once enabled, take the following steps to set trim variables to desired values.

- Select either 1 Point (one-point trimming) or 2 Points (two-point trimming) by clicking the appropriate button. Each pair consists of Set Value and Trim Value fields. The following prompt will appear:
- <u>Warning:</u> Please confirm you wish to do this. Changing the trimming mode will reset the trimming values. Changing the Relative
- Humidity will affect the Dew Point. It is recommended to trim the Relative Humidity before trimming the Dew Point.
- 2. Hit "YES" button to continue or "No" button to abort.
- 3. Enter the values that require trimming into the *Set Value* field.
- 4. Apply the targeted signal to the input, wait until it settles, and click *Trim* to capture the measured value.
- 5. If you chose *2 Points*, repeat the steps above for the second point.

Trimming data resides in the HSM allowing for factory service or user-trimming which is independent from the installed display assembly.

<u>Note:</u> Once you have configured all parameters, download to the unit by selecting Download in the Transfer dropdown menu located in the Status Bar. Or, click the I button in the Tool Bar.

Display

Figure 11. Display Tab for Firmware Versions Pre 2.0

Input Trimming Display Analog Output	1 Analog Output 2
Display Source Temperature (PV) Relative Humidity (SV) Dew Point (TV) Output Current (A01) Output Current (A02) Scoll	When the scroll display option is selected, the display will go through all five variables, PV, SV, TV, A01, and A02.
Custom Label	The custom label is applied to the PV when enabled.
Precision Decimal Places	

Figure 12. Display Tab for Firmware Versions 2.0 and Higher

Input Trimming Display Analog C	Dutput 1 Analog Output 2
	Select the items you would like to appear on the display. At least one item must be selected.
Custom Label	The custom label is applied to the PV when enabled.
Precision Decimal Places	

Display

Display Source– From here you may select which variable is viewed on your instrument's display (HDM) by clicking the desired variable.

By selecting the Scroll option, your display will toggle through each of the variables every four seconds displaying each setting.

From here you may select which variable is viewed on your instrument's display (HDM) by clicking the desired variable.

For units with HDM firmware pre 2.0 the Scroll option is available, with this your display will toggle through each of the variables every four seconds displaying each setting.

For unites with HDM firmware 2.0+ you can select multiple items to be displayed. Any combination is acceptable as long as at least one is selected.

Use Custom Label– (Applicable only to Temperature display)

Allows you to assign a specific label (alphanumeric, 5 characters max.), or EGU (Engineering Unit).

- 1. Check the *Use custom label* box.
- 2. Enter the value you wish viewed into the *Custom Label* text box.

Precision– Select the number of decimal places/ resolution of your display. Allowed settings are Auto, 0, 1, 2 or 3 decimal places.

Note: Once you have configured all parameters, download to the unit by selecting Download in the Transfer drop down menu located in the Status Bar. Or click the status in the Tool Bar.

Analog Output

Steps discussed in this section apply to both the Analog Output 1 and Analog Output 2 tabs of the HTZ PC Configuration Software.

Figure 13	Analog	Output	(-AO)	Tab
-----------	--------	--------	-------	-----

Input Trimming Display Analog Output 1	Analog Output 2	
Source	Output Current	
Relative Humidity (SV)	8.453 mA	
Source Range	Trimming	
0 to 100	Fix Output at Lower Output Range	
Output Range	Fix Output at Upper Output Range Upper	
4 to 20 mA		
Under Range Min. Value 3.8 mA (3.6 - 4.0 mA)	Measured Loop Current 0 mA	
Over Range Max. Value 21.8 mA (20.0 - 23.6 mA)	Trim	
Fail Mode		
High (20.0 - 23.6 mA)	Unfix Output Unfix	
Low (3.6 - 4.0 mA)	Resets analog output trimming. Reset	1
Hold Last		
23.6 mA	Output Test	
Damping	Fix current 0 Fix	
Enabled 0 s ()	(3.6 - 23.6 mA)	
	Unfix Output Unfix	

Source– This user-configurable parameter defines the variable that the analog output will monitor. By default, AO1 monitors the humidity value; AO2 monitors temperature.

Source Range– These values reflect the *Lower Range* and *Upper Range* values as displayed in the *Sensor Range* section of the *Input* tab.

Output Range– Sets the analog output range limits. Default value is 4-20mA.

- 1. Enter your low and high limit values into the text boxes.
- 2. In the *Under Range Min. Value* box, enter the lowest value your output can reach (typically between the Fail Low and the Zero % output value). The allowed limits are 3.6mA to 4.0mA. Default is 3.8mA.
- 3. In the Over Range Max. Value box, enter the highest value your output can reach (typically between the Fail High and the 100% output value). The allowed limits are 20.0mA to 23.6mA. Default is 21.8mA.

Fail Mode– In the case of an input failure, you have the ability to set a mode you choose to alert of the failure.

- **High** Choosing this option will send the output to a High fail mode (user-selectable between 20.0mA to 23.6mA).
- Low Choosing this option will send the output to a Low fail mode (user-selectable between 3.6mA to 4.0mA).
- Hold Last –This will display the last value present before the failure.

The *Sensor Error Value* box displays your selected value.

Damping– Output Damping allows you to introduce a delay (0-30sec) into the response of your unit in order to stop short-lived spikes from setting off alarms.

- 1. Select *Enabled* if you choose to use Damping.
- 2. Enter your damping time into the associated text box.

Output Current – Displays the value present at your output when the PC Configuration Software is in *Monitor* mode.

Trimming– Output Trimming increases the accuracy of your instrument by calibrating its analog output to the device that is receiving the output. This ensures that the instrument is being correctly interpreted.

- 1. Click the *Lower* button to trim the Lower Output Range.
- 2. To "fine tune" trimmed values, place the value read on the external multimeter, connected to your instrument for trimming, in the *Measured Loop Current* text box and click *Trim*.
- 3. Click the *Upper* button and repeat Step 2 to trim the Upper Output Range.
- 4. Once you have performed your output trimming, click *Unfix*.

<u>Note:</u> Do not click the Reset button in the Trimming menu unless you want to disregard your trimmed values and return to the manufacturer's trim values.

Output Test– This test may be performed in order to check output performance and accuracy and to trim other instruments in your setup. Your output will be a current value, in mA, equal to the value you enter into the text box. You can check the other devices on the system and calibrate them to this signal.

This feature is independent of the input. If you find that the output requires adjustment, you may perform the Trimming function.

- 1. Ensure that HTZ monitoring is stopped. In the *Fix current* text box, enter a value between 3.6-23.6mA and click the *Fix* button.
- 2. Return to monitoring the HTZ. You will see the "fixed" value in the *Output Current* display and on the external multimeter.
- 3. Once you have finished, click Unfix.

Note:

Once you have configured all parameters, download to the unit by selecting Download in the Transfer dropdown menu located in the Status Bar. Or, click the Jutton in the Tool Bar.

Using the HART Communicator

The HTZ can be programmed using a HART Communicator. If your communicator is equipped with the Device Description (DD) for your transmitter, *The HART Communicator Menu with a Device Description* section gives an overview of the menus and instructions for programming.

The HTZ DDs are available on the HART Foundation's Device Driver Library Release December 2007 and later. To determine if your communicator has the appropriate Device Description, follow the manufacturer's instructions. A list of companies will appear which, if you have the appropriate Device Description, will include Moore Industries HTZ.

If your communicator is *not* equipped with the required Device Description, go to *The HART Communicator Menu without a Device Description* section of this manual. Some capabilities can only be accessed if your communicator is equipped with the proper Device Description. If you are using a Fisher-Rosemount Model 375 HART Communicator, you may download the latest Moore Industries DD at www.miinet.com.

If you are using a Fisher-Rosemount Model 275 HART Communicator and require the latest version of the DD, you must either send the Communicator to Moore Industries or the HART Foundation. To send the instrument to Moore Industries contact our Customer Service department for a Returned Material Authorization (RMA).

Include Moore Industries' configuration sheet indicating the Device Descriptions that you require. We will load the Device Descriptions of your choice for a nominal charge.

For installation of the latest device description through the HART Foundation, contact the HART Communication Foundation at the location below:

> HART Communication Foundation 9390 Research Blvd., Suite I-350 Austin, TX 78759-6540 USA Phone: (512) 794-0369 Fax: (512) 794-3904 www.hartcomm.org

Ensure that you contact the HART Foundation to determine their requirements in sending the instrument to their facility.


Programming When a Device Description is Available

With the transmitter connected, apply power and turn on the communicator. After a brief self-test, the communicator will show the main menu and identify the unit as an HTZ.

This section contains the instructions for programming the transmitter using a HART Communicator that has been programmed with a HART Device Description. If your communicator does not have the appropriate Device Description, skip to *The HART Communicator Menu without a Device Description* section of this manual.

Figure 14 shows an overview of the programming menus for the configuration process.

Figure 14. HTZ HART Communicator Configuration Menu Summary



The HART Communicator Menu With a Device Description

To program your HTZ, if your communicator is equipped with the Device Description for your instrument, follow the steps below. For all steps outlined below, refer to Figure 14 for menu parameters.

1. Online Menu– The *Online* menu displays the present process value of your application, the PV lower and upper range values and the actual output current (-AO1 and -AO2). Use the *Device Setup* menu to configure the HTZ.

2. Device Setup Menu– The *Device Setup* menu allows you to access the following menus: *Process Variable, Setup, Diagnostic & Services and Review.*

3. Process Variable Menu– The *Process Variable* menu displays the present values of parameters listed on the Communicator display which include the Primary, Second and Third Variables (PV, SV and TV) and analog outputs (AO1 and AO2).

4. Setup Menu– Scroll through the *Setup* menu to access configuration menus for the following parameters: *Configure Inputs, Configure Output, Configure Dev Info and Configure Display.*

A. Configure Inputs

This menu allows access to input configuration.

1 *Filter*– This is used to configure the input filter which helps reduce mains-induced noise. The value selected should match the frequency of the local AC supply (50Hz or 60Hz).

2 EGU Selection– Specify an EGU setting using this parameter. This affects the PV and TV. The SV has a constant EGU read in percentage (%).

3 PV LRV / 4 PV URV– Select your primary process variables (Temperature) lower and upper range values, respectively. Ranges are displayed in temperature.

5 SV LRV / 6 SV URV– Select your primary process variables (Relative Humidity) lower and upper range values, respectively. Ranges are displayed in percentage.

7 TV LRV / 8 TV URV– Select your primary process variables (Dew Point) lower and upper range values, respectively. Ranges are displayed in temperature.

9 *PV Snsr S/N*– Enter your Temperature sensor's serial number.

10 Sensor Information– Displays the Lower Sensor Limit (LSL), Upper Sensor Limit (USL) and the minimum span of PV, SV and TV of the HTZ.

B. Configure Output

This menu allows you to configure the analog outputs (-AO1 and -AO2) as well as the HART output (-AO1 only).

Analog Output

These instructions apply to both -AO1 and -AO2 configuration. By default, AO1 monitors humidity; AO2 monitors temperature. You may select to change this.

1 AO1 Source– Select the variable that this output will monitor.

2 AO1 Zero– Enter your zero range output value. This value corresponds to the unit of measure (°C, °F or Kelvin) as selected in the EGU selection section. Default value is 4mA.

3 AO1 Full– Enter your upper range output value. Allowed values range from 3.6mA to 23.6mA. This value corresponds to the unit of measure (°C, °F or Kelvin) as selected in the EGU selection section. Default value is 20mA.

4 AO1 Damping Rate– Damping allows you to introduce a delay into the response for your unit in order to stop short-lived spikes from setting off alarms. To utilized damping, select a value between 0-30sec.

5 AO1 URV– Select a value between 3.6mA and 4.0mA as your analog output under range value (AO1 URV). If the analog output drops below the set value, a fault will be declared. Default value is 3.8mA.

6 AO1 ORV– Select a value between 20.0mA and 23.6mA as your analog output over range value (AO1 ORV). If the analog output exceeds the set value, a fault will be declared. Default value is 21.8mA.

7 AO1 Fail Mode– In the case of an input failure, you have the ability to set a mode you choose to alert of the failure. Select from:

High– Choosing this option will send the output to a High fail mode (user-selectable between 20.0mA to 23.6mA). If selecting High fail mode, enter your value in the following step (*Fail AO1*).

HTZ Smart HART[®] Humidity and Temperature Transmitter

Low– Choosing this option will send the output to a Low fail mode (user-selectable between 3.6mA to 4.0mA). If selecting Low fail mode, enter your value in the following step (*Fail AO1*).

Hold Last– Selecting this will display the last value present before the failure occurred.

8 *Fail AO1*– Select your High or Low fail mode value. Allowed values are 20.0mA to 23.6mA for High Fail mode and 3.6mA to 4.0mA for Low Fail mode.

9 AO1 Trim– Output trimming increases the accuracy of your instrument by calibrating its analog output to the device that is receiving the output. This ensures that the instrument is being correctly interpreted.

Connect a multimeter to your HTZ output to indicate present output reading.

Setting fld device to Output Zero will be displayed on your communicator. Select OK if ready to proceed. When prompted, enter the value displayed on the multimeter into your communicator. Press Enter. If your output matches the value on the multimeter, select Yes.

Next, Setting fld dev to Out Full is displayed on your communicator. Select OK if ready to proceed. When prompted, enter the value displayed on the multimeter into your communicators. Press Enter. If your output matches the value on the multimeter, select Yes.

10 AO1 Trim Reset– Select this in order to use manufacturer's trim values.

<u>Note:</u> Do not perform the Output Trim Reset function unless you want to disregard your trim values and return to the manufacturer's values

Repeat Steps 1 to 10 to configure -AO2, if required.

HART Output

Use this portion of the menu to configure the Poll Address, Burst mode and Burst Option.

1 *Poll addr*– The HART polling address is represented by a number between 0 and 15. This identifies the transmitter on the loop. In a loop with only one HART slave on it, this address should be 0. In a multidrop loop, any of these numbers can be used.

<u>Note:</u> If the polling address is set to 0, the transmitter is automatically set to analog mode. Multiple units on the same bus must have different addresses. 2 Burst mode- This function allows you to achieve a higher data rate. When enabled (On), your instrument repeatedly transmits a data message as if it were being commanded to do so. The Master device receives the data more frequently than if it were only polling the transmitter, achieving a higher data transfer rate.

3 Burst option– Once Burst Mode is enabled, choose which value is transmitted–*PV, % range/current* or *Process vars/crnt* (Process variables/current).

C. Configure Dev Info

This menu allows you to configure identification parameters for your HTZ.

1 Tag– Place a unique label that corresponds to your instruments location or specific usage (8 characters maximum).

2 *Descriptor*– Place text that is used as a description of how the instrument is being used (16 characters, maximum).

3 *Message*– Place additional information that may be helpful in describing the instrument or its use (32 characters, maximum).

4 Date– Store a date that corresponds to specific system function, i.e. instrument configuration date, calibration due date, preventive maintenance schedule, etc.

5 *Final asmbly num*– You may enter a number that is used for identification purposes, and is associated with the field device (8 characters, maximum).

6 *Dev id*— This is a read-only value that uniquely identifies the field device when combined with the manufacturer identification and device type.

7 *Hardware rev*– This is a read-only value that corresponds to the revision of the electronics hardware of the field device.

8 HSM Device ID– Displays the device identification of the connected Humidity/Temperature Sensor Module (HSM).

9 *HSM HW Rev.*– Displays the hardware revision of the connected Humidity/Temperature Sensor Module (HSM).

10 HSM FW Rev.– Displays the firmware revision of the connected Humidity/Temperature Sensor Module (HSM).

D. Configure Display

This menu describes configuration of HTZ display settings as viewed on the (Humidity/Temperature Display Module) HDM.

1 Mode– Select which variable is displayed–PV, SV, TV, AO1, AO2 or scroll through each value.

2 Decimal Places– Choose the resolution of your value. Select one, two or three decimal places. You may also choose *Auto* to allow the instrument to automatically select the decimal placement.

3 *Custom Label*– Enable or disable custom label for use on the display.

4 Label Displayed– Select your custom label. Enter all capitalized characters or an accepted numeric value. This is applied to the PV only.

5. Diagnostic & Service Menu– Allows you to perform diagnostic functions and trimming.

1 Test device— Directs you to a *Status* sub-menu. When accessed, it causes the HTZ to perform a self test of its electronics. Any errors that occur are reported on the communicator.

Trimming– Trimming increases the measurement accuracy of your instrument by matching the reading of its actual input, to either a calibrated source or the device to which it is connected. This verifies that the input to the transmitter is being interpreted correctly.

You may trim any point between 0% and 100% along the scale. Note that One Point trimming applies an offset to the sensor reading, while Two Point trimming applies both an offset and a gain.

You may perform Relative Humidity and Dew Point trimming.

Trimming data resides in the HSM allowing for factory service or user-trimming independent of the installed display assembly.

2 *PV Trimming*– Allows you to view Temperature Trimming functions.

Trim Mode–Displays that Trim Mode is *Off* (due to previous factory calibration).

3 *SV Trimming*– Allows you to view and/or set Relative Humidity Trimming functions.

Enter the menu. You will notice two separate warning messages that will appear. The first warning reminds

the user that the *Loop should be removed from automatic control*. Select *OK* or *Abort* and follow the prompts.

The second warning regarding executing trimming notifies the user that *This will affect sensor calibration.* Again, select *OK* or *Abort* and follow the appropriate prompts.

Next, select the *Trim Mode* that you will use. Choose Off, One Point or Two Point trimming. If you choose not to perform trimming, select *Off.* When you have made your selection, select *OK*.

<u>Note:</u> Selecting Off in Trim Mode returns trimming to the factory calibrated value.

In the text box that appears, enter your lower trim point value and select *OK*.

Next, enter your desired upper trim point value; click *OK.*

The following message will appear: *The trim will now be reset prior to trim.* If you are satisfied with the lower and upper trim points that you have selected, choose Yes and click *OK.* If your values require modification, select *No* and then *OK.* Return to adjusting the upper and lower trim points.

At the next menu item, wait until your input reading stabilizes and select *OK*.

Trim Mode—This menu allows you to view whether or not Relative Humidity Trim Mode is presently configured.

4 TV Trimming– Allows you to view and/or set Dew Point Trimming functions.

Trim Mode—This menu allows you to view whether or not Dew Point Trim Mode is presently configured.

Dew Point Trimming– Repeat steps described in *SV Trimming* section.

5 Loop Test- (Instructions apply to -AO1 and -AO2) A loop test may be performed in order to check output performance and accuracy and to trim other instruments in the loop. Your output will be a current value, in mA, equal to the value you input. You can check the other current devices on the loop and calibrate them to this signal.

From the menu, select whether to perform the test at 4mA (low end value), 20mA (upper end value) or at another specified value. Once you have competed your test, select *End*.



6. Review Menu–This is a read-only menu that provides information on both *Device Parameters* and *Device Information*. Refer to the *Review* menu portion of Figure 14 for a description of the parameters included in this menu.

The HART Communicator Menu Without a Device Description

This section contains the instructions for programming an HTZ using a HART communicator without a Device Description. If your communicator has a Device Description, please see *The HART Communicator Menu with a Device Description* section of this manual.


1. Online Generic– The initial screen, the *Online Generic* menu, displays the process value, analog output and the programmed upper and lower parameters of the process value. The generic HART Communicator overview menu shows the screen. Use the *Device Setup* menu for configuring your HTZ.

2. Basic Setup– The *Basic Setup* menu allows you to enter a name for an individual transmitter, the units of measurement, the upper and lower range and sensor values and a damping time between 0sec and 30sec.

3. Analog Output– The *Analog Output* menu displays the analog output, changes the loop current to a fixed value so that it can be checked against the value being received and displayed by your receiving device, and enters and trims the sensor.

4. HART Output– From the *HART Output* menu, you can enter the polling address and display the number of preamble characters sent by the master to the slave to ensure synchronization.

If the polling address is set to 0, the HTZ is automatically set to analog mode. Multiple units on the same bus **must** have different addresses.



HART Status Information

Each time the HTZ generates a response, frame status information is included in the reply message. The first byte indicates communications errors, if any. Otherwise, if communication was good, this byte may indicate the status of the received command. The

second status byte indicates the operational state of the slave device. A properly operating slave device will have both status bytes set to logic zero.

The following tables include the common information that is returned in every response message.

Table 2. Communications Errors

Bit 7 = 1	
Bit	Description
0	Undefined
1	Buffer Overflow
2	Reserved set to zero.
3	Checksum Error
4	Framing Error
5	Overrun Error
6	Parity Error
7	This bit is always set when Communication errors occur

Table 3. Command Errors

Bit 7 = 0		
Value	Hex	Description
0	0x00	No command Errors
1	0x01	Undefined Error
2	0x02	Invalid selection
3	0x03	Passed Parameter too large
4	0x04	Passed Parameter too small
5	0x05	Too Few bytes received
6	0x06	Transmitter Specific Command Error
18	0x12	Invalid UOM Code
32	0x20	Transmitter Busy
64	0x40	Command not supported

Table 4. Device Status Bytes

Warning Warning Warning	Primary Variable Out of Limits. The process applied to the sensor for the Primary Variable is beyond the operating limits of the device. Non-Primary Variable Out of Limits. The process applied to a sensor, other than that of the Primary Variable, is beyond the operating limits of the device. Command #48, Additional Status Information, may be required to identify the variable. Analog Output Saturated. The analog and digital outputs for the Primary Variable are beyond their limits
	Variable, is beyond the operating limits of the device. <i>Command</i> #48, <i>Additional Status Information</i> , may be required to identify the variable. Analog Output Saturated. The analog and digital outputs for the Primary Variable are beyond their limits
Warning	
	and no longer represent the true applied process.
Warning	Analog Output Current Fixed. The analog and digital outputs for the Primary Variable are held at the requested value. They will not respond to the applied process.
Warning	Additional Status Available. More status information is available than can be returned in the Field Device Status. <i>Command</i> #48, <i>Additional Status Information</i> may be required to identify the variable.
Warning	Cold Start. Power has been removed and reapplied resulting in the reinstallation of the setup information. The first command to recognize this condition will automatically reset this flag. This flag may also be set following a Master Reset or a Self Test.
Warning	Configuration Changed. A write or set command has been executed.
Error	Device Malfunction. A hardware error or failure has been detected by the device. Further information may be available through <i>Command</i> #48, <i>Additional Status Information</i> .
V	Warning Warning Warning

Table 5. Process Variable Error Displayed Message	Table 5.	Process V	/ariable Eri	ror Displaved	Messages
---	----------	-----------	--------------	---------------	----------

Error Condition	Displayed Message		
Configuration Information Bad	ERROR CONFG		
Calibration Information Bad	ERROR CALIB		
HDM EEPROM Blank	ERROR BLANK		
HDM EEPROM Error	ERROR EEROM		
Maths division by zero error	ERROR DZERO		
Humidity Sensor Error	ERROR HUMDT		
Software Watchdog failure	ERROR SWARE		
Hardware Error	ERROR HWARE		
Wire 1 (Temperature Input) Broken	WIRE1 BROKE		
Wire 2 (Temperature Input) Broken	WIRE2 BROKE		
Wire 3 (Temperature Input) Broken	WIRE3 BROKE		
Wires (Temperature Input) Broken	WIRES BROKE		
HSM Communication Error	ERROR HSM		
Temperature Input Out of range	ERROR RANGE		
Temperature Input Saturated	ERROR INSAT		
Relative Humidity Input Out of range	ERROR RNG H		
Dew Point Input Out of range	ERROR RNG D		
HSM ADC Error	ERROR ADC		
HSM Disconnected	HSM NOCON		
HSM EEPROM Corrupted or Blank	ERROR HSMEE		
Initializing HSM and/or HDM	HTZ X INIT		
	HTZ + INIT		
HTZ Busy setting configuration	HTZ X INIT		
	HTZ + INIT		

HART Commands

Table 6 indicate the HART commands which the HTZ supports. Tables 7 and 8 provide specific information regarding Commands 48 (Read Additional HART Status Information) and 108 (Burst Mode).

Command 48

The *Read Additional HART Status Information* section, accessible via the *View* dropdown menu when using Moore Industries' PC Configuration Software, or through the handheld communicator, returns six additional HART status information bytes in response to HART Command 48–*Read Additional HART Status Information*. Refer to Table 7 for these data bytes.

Table 6. Supported HART Commands

Command	Description
33	Read Transmitter Variables
35	Write PV range values
36	Set PV upper range value
37	Set PV lower range value
38	Reset "configuration changed"
40	Enter / Exit fixed current mode (AO1)
43	Set PV zero
44	Write PV units
45	Trim DAC zero (AO1)
46	Trim DAC full (AO1)
48	Additional status information
49	Write PV sensor serial number
108	Write burst mode command number
109	Burst mode control

Command 108

When enabled, Burst Mode configuration which is accessible through the *Burst Mode* dropdown menu when using Moore Industries' PC Configuration Software or through the handheld communicator, allows you to achieve a higher data rate by allowing your instrument to repeatedly transmit a data message as if it were being commanded to do so. The Master device receives the data more frequently than if it were only polling the transmitter, achieving a higher data transfer rate. Refer to Table 8 for the associated data bytes.

Status Byte	Status Word Bit	Туре	Description
0	0	Error	Configuration data error
	1	Error	Calibration data error
	2	Error	EEPROM blank
	3	Error	EEPROM failure
	4	Error	Division by zero error
	5	Error	SHT Error
	6	Error	Software watchdog failure
	7	Error	COP watchdog failure
1	0	Error	Sensor wire 1 broken
	1	Error	Sensor wire 2 broken
	2	Error	Sensor wire 3 broken
	3	Status	Sensor wires broken
	4	Status	Busy / Calibration, trimming active
	5	Error	Configuration data area checksum error
	6	Error	Calibration data area checksum error
	7	Error	Front-end / Back-end communications failure
2	0	Status	Temperature Out of range error
	1	Status	Temperature Input Saturation
	2	Status	Relative Humidity Out of range error
	3	Status	Dew Point Out of range error
	4	Error	ADC Error
	5	Error	AO2 Saturated Error
	6	Status	AO2 Fixed
	7	Error	HSM Disconnected
3	0-7	Not used	Set to zero
4	0-7	Not used	Set to zero
5	0-7	Not used	Set to zero

 Table 7
 HART Read Additional HART Status Information (Command 48) Data Bytes

Table 8. HART Burst Mode (Command 108) Data Bytes

Command	Description
1	Read Primary Variable
2	Read Current and Percent of Range
3	Read current and dynamic variables

Notes: 1. Command 108 will specify the burst command number. 2. Command 109 will allow control of burst mode.

Installation

Installation consists of physically mounting the unit and completing the electrical connections.

Mounting

The HSM mounts using either our standard Z plate or P-Bracket. The Z plate assembly has two plates attached to each other with wing nuts, which are easily removed, allowing for easy separation without the need for tools. It then mounts to a duct or other specified location.

The P-Bracket is used in applications where mounting is required onto a flat surface or pipe mounting.

When HSM is Z plate mounted, ensure that both the humidity and temperature probes are in contact with air flow. As a guide for placement, The HSM back plate is stamped with <<*FLOW DIRECTION*>>.

A 2-inch pipe mount hardware kit comes standard on the HDM to facilitate mounting to a pipe or pole. This can be removed for flat surface mounting.

Making the Electrical Connections

Refer to pages 11 and 12 for electrical connections.

Recommended Ground Wiring Practices

Moore Industries recommends the following ground wiring practices:

- Any Moore Industries product in a metal case or housing should be grounded.
- The protective earth conductor must be connected to a system safety earth ground before making any other connections.
- All input signals to, and output signals from, Moore Industries' products should be wired using a shielded, twisted pair wiring technique. Shields should be connected to an earth or safety ground.
- For the best shielding, the shield should be run all the way from the signal source to the receiving device. (see Note below)
- The maximum length of unshielded input and output signal wiring should be 2 inches.

<u>Note:</u>

Some of Moore Industries' instruments can be classified as receivers (IPT2, IPX2, etc.) and some can be classified as transmitters (TRX, TRY, etc.) while some are both a receiver and a transmitter (SPA2, HIM, etc). Hence, your shield ground connections should be appropriate for the type of signal line being shielded. The shield should be grounded at the receiver and not at the signal source.

Additional Grounding Information

The HSM will be properly grounded once it is mounted onto the Z-plate, provided that this plate has been installed onto a grounded metal A/C duct or grounded by some other means. When mounted on P-Bracket use the supplied ground screw to ground unit. Also, the supplied quick-disconnect cable will establish a ground path to the HDM once a connection has been made between both units. To avoid grounding at different potentials, the HDM has been isolated from its outer enclosure. **DO NOT** provide an external ground to this unit.

CE Conformity

Installation of any Moore Industries' products that carry the CE and/or UKCA marking <u>must</u> adhere to the guidelines in the Recommended Ground Wiring Practices section in order to meet the EN 61326 requirements set forth in the applicable EMC Directive and Regulation.

Operation

Once programmed, calibrated, installed, and supplied with the correct power, the HTZ begins to operate immediately. Depending upon environmental conditions, it can be expected to operate unattended for extended periods of time.

Maintenance

Moore Industries suggests a quick check for terminal tightness and general unit condition every 6-8 months. Always adhere to any site requirements for programmed maintenance.

Calibration

The following are Moore Industries' calibration recommendations.



Temperature Probe

The temperature probe should be checked for proper operation once a year at customer's facility. The probe should be sent to Moore Industries for calibration once every five years.

Relative Humidity Probe

The relative humidity probe should be checked for proper operation once a year at customer's facility.

Humidity can be trimmed to match customer standards using calibrated instrumentation for humidity measurements.

To replace the RH sensor, carefully remove the porous cap, extract the old RH sensor and insert the new one observing proper polarity.

<u>Caution:</u> Be sure to observe proper polarity when replacing the sensor. Erroneous polarity may severely damage the RH sensor.

Replacing the RH sensor will render any previous RH trimming offsets applied to the instrument invalid. New trimming constants must be redefined.

Figure 16. RH Sensor Replacement

Customer Support

Moore Industries is recognized as the industry leader in delivering top quality to its customers in products and services. We perform a battery of stringent quality assurance checks on every unit we ship. If any Moore Industries product fails to perform up to rated specifications, call us for help. Our highly skilled staff of trained technicians and engineers pride themselves on their ability to provide timely, accurate, and practical answers to your process instrumentation questions.

Factory phone numbers are listed on the back cover of this manual.

If problems involve a particular module, there are several pieces of information that can be gathered **before you call the factory** that will help our staff get the answers you need **in the shortest time possible**. For fastest service, gather the complete model and serial number(s) of the problem unit(s) and the job number of the original sale.

RETURN PROCEDURES

To return equipment to Moore Industries for repair, follow these four steps:

1. Call Moore Industries and request a Returned Material Authorization (RMA) number.

Warranty Repair -

If you are unsure if your unit is still under warranty, we can use the unit's serial number to verify the warranty status for you over the phone. Be sure to include the RMA number on all documentation.

Non-Warranty Repair -

If your unit is out of warranty, be prepared to give us a Purchase Order number when you call. In most cases, we will be able to quote you the repair costs at that time. The repair price you are quoted will be a "Not To Exceed" price, which means that the actual repair costs may be less than the quote. Be sure to include the RMA

number on

all documentation.

- 2. Provide us with the following documentation:
 - a) A note listing the symptoms that indicate the unit needs repair
 - b) Complete shipping information for return of the equipment after repair
 - c) The name and phone number of the person to contact if questions arise at the factory
- 3. Use sufficient packing material and carefully pack the equipment in a sturdy shipping container.
- 4. Ship the equipment to the Moore Industries location nearest you.

The returned equipment will be inspected and tested at the factory. A Moore Industries representative will contact the person designated on your documentation if more information is needed. The repaired equipment, or its replacement, will be returned to you in accordance with the shipping instructions furnished in your documentation.

WARRANTY DISCLAIMER

THE COMPANY MAKES NO EXPRESS, IMPLIED OR STATUTORY WAR-RANTIES (INCLUDING ANY WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE) WITH RESPECT TO ANY GOODS OR SERVICES SOLD BY THE COMPANY. THE COMPANY DIS-CLAIMS ALL WARRANTIES ARISING FROM ANY COURSE OF DEALING OR TRADE USAGE, AND ANY BUYER OF GOODS OR SERVICES FROM THE COMPANY ACKNOWLEDGES THAT THERE ARE NO WARRANTIES IMPLIED BY CUSTOM OR USAGE IN THE TRADE OF THE BUYER AND OF THE COMPANY, AND THAT ANY PRIOR DEALINGS OF THE BUYER WITH THE COMPANY AND TMAT ANY PRIOR DEALINGS OF THE BUYER WITH THE COMPANY DO NOT IMPLY THAT THE COMPANY WARRANTS THE GOODS OR SERVICES IN ANY WAY.

ANY BUYER OF GOODS OR SERVICES FROM THE COMPANY AGREES WITH THE COMPANY THAT THE SOLE AND EXCLUSIVE REM-EDIES FOR BREACH OF ANY WARRANTY CONCERNING THE GOODS OR SERVICES SHALL BE FOR THE COMPANY, AT ITS OPTION, TO REPAIR OR REPLACE THE GOODS OR SERVICES OR REFUND THE PURCHASE PRICE. THE COMPANY SHALL IN NO EVENT BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES EVEN IF THE COMPANY FAILS INANY ATTEMPT TO REMEDY DEFECTS IN THE GOODS OR SERVICES, BUT IN SUCH CASE THE BUYER SHALL BE ENTITLED TO NO MORE THAN A REFUND OF ALL MONIES PAID TO THE COMPANY BY THE BUYER FOR PURCHASE OF THE GOODS OR SERVICES. ANY CAUSE OF ACTION FOR BREACH OF ANY WARRANTY BY THE COMPANY SHALL BE BARRED UNLESS THE COMPANY RE-CEIVES FROM THE BUYER A WRITTEN NOTICE OF THE ALLEGED DEFECT OR BREACH WITHIN TEN DAYS FROM THE EARLIEST DATE ON WHICH THE BUYER COULD REASONABLY HAVE DISCOVERED THE ALLEGED DEFECT OR BREACH, AND NO ACTION FOR THE BREACH OF ANY WARRANTY SHALL BE COMMENCED BY THE BUYER ANY LATER THAN TWELVE MONTHS FROM THE EARLIEST DATE ON WHICH THE BUYER COULD REASONABLY HAVE DISCOV-ERED THE ALLEGED DEFECT OR BREACH.

RETURN POLICY

For a period of thirty-six (36) months from the date of shipment, and under normal conditions of use and service, Moore Industries ("The Company") will at its option replace, repair or refund the purchase price for any of its manufactured products found, upon return to the Company (transportation charges prepaid and otherwise in accordance with the return procedures established by The Company), to be defective in material or workmanship. This policy extends to the original Buyer only and not to Buyer's customers or the users of Buyer's products, unless Buyer is an engineering contractor in which case the policy shall extend to Buyer's immediate customer only. This policy shall not apply if the product has been subject to alteration, misuse, accident, neglect or improper application, installation, or operation. THE COMPANY SHALL IN NO EVENT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.



United States • info@miinet.com Tel: (818) 894-7111 • FAX: (818) 891-2816 Australia • sales@mooreind.com.au Tel: (02)8536-7200 • FAX: (02) 9525-7296

Demand Moore Reliability www.miinet.com BeNeLux • info@mooreind.eu Tel: 03/448,10,18 • FAX: 03/440,17,97

China • sales@mooreind.sh.cn Tel: 86-21-62491499 • FAX: 86-21-62490635 United Kingdom • sales@mooreind.com Tel: 01293 514488 • FAX: 01293 387752