

June 2023 170-775-00L



(I/P) Transmitters

Current-to-Pressure (I/P) Transmitters DH² & F





Table of Contents

Introduction	3
The IPH ² & IPX ²	3
Specifications	4
IPX ² Dimensional Diagram	5
IPH ² Dimensional Diagram	6
Calibration	7
Necessary Equipment and Calibration Preparation	7
Calibration Process	
Installation	
Phase One: Mounting	
Phase Two: Electrical Connections	
Phase Three: Pneumatic Connections	
Hazardous Location Applications	
Operation	
Maintenance	
Troubleshooting the IPH ² & IPX ²	14
IPX ² Replacement Modules	14
Customer Service	
Intrinsically Safe Diagram	16
Return Procedures	

2



Introduction

This users' manual for Moore Industries' IPH^2 and IPX^2 Current-to-Pressure Transmitters contains all of the information that is needed to calibrate, install, operate, maintain, and troubleshoot this family of transmitters.

The following guidelines are used in this manual:

<u>*WARNING*</u> - Hazardous procedure or condition that could injure the operator.

<u>**Caution**</u> - Hazardous procedure or condition that could damage or destroy the unit.

<u>Note</u> - Information that is helpful for a procedure, condition, or operation of the unit.

About this Manual

Wherever you see a "<u>WARNING</u>", "<u>Caution</u>" or "<u>Note</u>" pay particular attention.

<u>**WARNING</u>** - Hazardous procedure or condition that could injure the operator.</u>

<u>**Caution**</u> - Hazardous procedure or condition that could damage or destroy the unit.

<u>**Note</u>** - Information that is helpful for a procedure, condition, or operation of the unit.</u>

IPH² & IPX²

The rugged IPH² and IPX² Current-to-Pressure (I/P) Transmitters are designed specifically for extended duty in harsh field environments. Being Type 3X/4X- and IP56/IP66-rated, the extruded aluminum housings, for both the IPH² and IPX², offer water and dust protection and are also highly resistant to corrosion and chemicals. In addition, while the air and natural gas versions of the IPX² are explosion-proof, the later offers an increased ingress protection of IP66.

These 2-wire (loop-powered) transmitters convert a current signal to a pneumatic signal so that an electronic-based system such as a DCS, PLC, or PC can control a pneumatic actuator, valve, or damper drive. Available models accept a wide range of current inputs (4-20mA, 4-12mA, and 12-20mA) and provide a proportional pneumatic signal (3-15psig, 0.2-1Bar, 20-100kPA, etc.). A reverse pneumatic output option is available for the IPH². Reverse output is switch selectable on new versions of the IPX² (introduced in 2013).

The high-performance line of I/P transmitters utilizes an internal feedback loop to ensure accurate operation. The feedback loop consists of an internal pressure transducer that samples the unit's output pressure and compares it to the input signal. This allows the unit's output to track the input signal. Other I/P transmitters, such as our original IPT, IPH and IPX models, rely solely on mechanical positioning.

Since the feedback loop requires power to operate, when there is no input power to the unit, the pneumatic output will be shut off. Units that use mechanical positioning only, will typically still have a pneumatic output when power is removed. By example, a unit (IPT, IPH and IPX) with an output range of 15 - 3PSIG will output approximately 18PSIG when the input signal is removed. This is not an issue except for those users that rely on this elevated output (18PSIG) to maintain a valve's position upon the unexpected loss of input signal (4-20mA). In such cases, the IPT², IPH² and IPX² units react differently by shutting off the pneumatic output.

Both units are available with an optional coalescing filter/regulator that combines an air filter and miniature supply line regulator with a pressure gauge that reads in both psi and Bars.


Specifications

Performance	Accuracy: <±0.25% of span including the combined effect of linearity, hysteresis and repeatability (between 0 and 3psig output, error will not exceed ±1.0% of span) Stability: Not to degrade from stated accuracy for six months Step Response: <0.25 seconds into 100ml load (6 in ³) from 10% to 90% of span; Not guaranteed below 3psig output Supply Pressure Effect: Negligible from 20-40psig, steady pressure Air Capacity: 5.0SCFM minimum (20psig supply, 0psig output) Relief Capacity: 2.5SCFM minimum (15psig output) Air Supply: Instrument air only, 20-40psig. (Must be	Performance (Continued)	Voltage Drop: 5V, maximum Air Consumption (Dead-ended): At 3-15psig output 20psig supply, average steady state consumption* of 4.7SCFH (min 4.2SCFH@ 3psig, max 5.2SCFH@15psig); 40psig supply, max 9SCFH @15psig output; 40psig supply, max 10SCFH @30psig output Natural Gas Consumption (Dead-ended): At 3-15psig output 20psig supply, average steady state consumption* of 5.7SCFH, (min 5.1SCFH@ 3psig, max 6.2SCFH@15psig); 17psig supply, max 5.9SCFH @15psig output; 40psig supply, max 12SCFH @30psig output;	Ambient Conditions	Operating & Storage Range: -40°C to +85°C (-40°F to +185°F) Ambient Temperature Effect: $<\pm 0.025\%$ of span/°C, maximum from -20°C to 80°C; $<\pm 0.1\%$ of span/°C, maximum RFI/EMI Effect: $<\pm 0.25\%$ of span change at in field strengths of 10V/m@ frequencies of 20-1000MHz Vibration Effect: Meets ANSI/ISA-75 13.01-1996 (R2007) 5.3.5 as follows: 5-15Hz, 2mm peak-to- peak; 15-150Hz, 1g; 150-2000Hz, 0.5g Relative Humidity: 0-100%, non-condensing
	5psig greater than maximum output) Gas Supply with -NG1 or -NG2 Option: 17-40psig.		Mounting Position Effect: Negligible, unit can be mounted in any position; refer to user manual for	Adjustment	Zero & Span: Screw adjusts zero or span by ±10% minimum, non- interactive
	Same cleanliness as instrument air. H ₂ S not to exceed 20ppm		special conditions of use with natural gas supply or outdoor environments.	Weight	IPH ² : 1.14kg (2.5 lbs) IPX ² : 2.4kg (5.3 lbs)

*Average flow rate determined at 9 psig output

Specifications and information subject to change without notice.









Figure 2. IPH² Current-to-Pressure Transmitter Housing Dimensions





Calibration

Every IPH² and IPX² is fully tested and calibrated at the factory prior to shipment. However, before installation, your IPH² or IPX² should be bench-checked to verify the desired unit zero and unit span. Calibration should be conducted in an appropriate testing environment.

Necessary Equipment

Table 1 lists the equipment required to calibrate the unit. This equipment is not supplied by Moore Industries, but should be available in most labs or maintenance areas.

Table 1. IPH² & IPX² Calibration Equipment

Equipment	Description
Adjustable current source	4-20mA output
DC Multimeter	Accurate to ±0.05%
Instrument air supply	Filtered
Air pressure gauge #1	Accurate to ±2%
Air pressure gauge #2	Accurate to ±0.1%
Pneumatic load	Volume of 7.5 cubic inches (approx. 120 milliliters)

Preparing for Calibration

To prepare the IPH² or IPX² for calibration, remove the screw-on cap and connect the unit to your configuration equipment as shown in Figures 3 and 4.

Unit Connections and Controls. The IPH² and IPX² each have two labeled terminals on their faceplate, located under the top protective cover of the housing. The terminal labeled "+PS" is for connection of the positive current input, and the terminal labeled "–PS" is for the negative connection.

The two controls are also located inside the unit housing under the screw-on cap. They consist of two potentiometers, each accessed through the front panel. They are labeled "zero" and "span". The zero potentiometer provides a control range for offsets of $\pm 10\%$ of rated unit span, while the span potentiometer adjusts unit full-scale output to 100 percent of rated span.

Each potentiometer requires approximately 20 turns to move its wiper from one extreme to the other: clockwise for maximum, or counterclockwise for minimum values. Each is equipped with a slip clutch to prevent damage if the adjustment is turned beyond the wiper stop. Note:

Always use clean, dry, instrument air when calibrating or operating the IPH² or IPX².

All pneumatic lines used in calibration and operation must be "blown down" (purged) prior to connection to the unit. Any condensation or oil residue in the lines, if introduced into the pneumatic chambers of the unit, may result in poor unit performance.

Calibration Process


To perform the recommended bench-check for the IPH² or IPX², first perform the setup as described in the next section. See Figures 3 and 4 for illustrations of the Calibration Setup, then follow the steps under Calibration Setup and Calibrating the IPH² or IPX².

Calibration Setup


- Connect 1/4-inch pneumatic tubing between the appropriate output port of the regulated instrument air supply and the pressure gauge #1 (accuracy of ±2% of span). Connect another tube from the pressure gauge to the port labeled "IN" on IPH² or IPX².
- Connect 1/4-inch pneumatic tubing between the port labeled "OUT" and the appropriate port of pressure gauge #2 (accuracy of ±0.1% of span), then from gauge #2 to the appropriate pneumatic load.
- Run current source wiring through conduit opening in housing, and to the front panel of the IPH² or IPX². (Not necessary for IPX² –NG models.)
- 4. Connect positive lead of adjustable current source to the +PS terminal of unit. Connect negative source lead to the –PS terminal. (For IPX² –NG, connect the positive lead of the current source to the red wire, and the negative lead of current source to the black wire.) A multimeter may also be connected to verify level of current input.
- 5. When connections are complete, apply an input current of 0% of span. (i.e. 4mA for a 4-20mA unit)
- 6. Apply appropriate filtered, instrument-quality air to supply line: 20 or 35psi (1.4Bar to 2.4Bar). Verify appropriate supply pressure by checking Supply Pressure field of unit model number.
- 7. Allow approximately 30 seconds for calibration setup to stabilize.



Figure 3. IPH² Calibration Setup







Calibrating the IPH² or IPX²

This calibration procedure consists of a basic check and adjustment of unit zero and span, based on the reading of pressure gauge #2. To calibrate a direct output unit, perform the following:

- 1. For IPX² new versions (introduced in 2013) only, check switch is set to "Direct"- see Figure 5.
- Check unit zero setting. Monitor reading of pressure gauge #2 (output), and turn zero potentiometer counterclockwise to lower output, clockwise to raise output. Set zero potentiometer so that pressure output is at 0% of span when a current input of 0% of span is applied. (i.e. 3psi for a 3-15psi unit)
- 3. Check unit span setting. Increase input to 100% of rated span (i.e. 20mA for a 4-20mA unit).
- Monitor reading of pressure gauge #2 (output), and adjust span potentiometer so that reading is at 100% of span for your unit (i.e. 15psi for a 3-15psi unit).
- 5. Repeat steps 1 through 4 until the unit outputs 0% of rated pressure range at 0% current input, and 100% of output pressure range at 100% of span.
- 6. Verify the accuracy of your adjustments by inputting 0%, 25%, 50%, and 75% of span inputs, and monitoring the output.

To calibrate a reverse output unit, perform the following:


- 7. For IPX² new versions (introduced in 2013) only, check switch is set to "Reverse" see Figure 5.
- Check unit zero setting. Monitor reading of pressure gauge #2 (output), and turn zero potentiometer counterclockwise to lower output, clockwise to raise output. Set zero potentiometer so that pressure output is at 100% of span when a current input of 0% of span is applied. (i.e. 15 psi for a 3-15 psi unit).
- 9. Check unit span setting. Increase input to 100% of rated span (i.e. 20mA for a 4-20mA unit).

- 10. Monitor reading of pressure gauge #2 (output), and adjust span potentiometer so that reading is at 0% of span for your unit (i.e. 3 psi for a 3-15 psi unit).
- 11. Repeat steps 8 through 10 until the unit outputs 100% of rated pressure range at 0% current input, and 0% of output pressure range at 100% of span.
- 12. Verify the accuracy of your adjustments by inputting 0%, 25%, 50%, and 75% of span inputs, and monitoring the output.

Note:

New versions of the IPX² (introduced in 2013) have a selectable output switch. Be sure to set this switch to the required output mode, direct or reverse, and use the corresponding set of pots accordingly. See Figure 5.

Figure 5. IPX² Output Switch



Installation

The installation of the IPH² or IPX² is carried out in three phases: the physical mounting of the unit, the electrical connections phase, and the pneumatic connections phase. It is strongly suggested that each unit be calibrated according to the instructions in this manual before being placed into service.

Installation in hazardous 'Classified' locations and potentially explosive atmospheres must adhere to the instructions in the Hazardous Location Applications section which can be found at the end of this Installation section.

Phase One: Mounting

Figures 1 and 2 give the dimensions of the IPX² and IPH², respectively. The illustrations also give the dimensions of the available option hardware, which is recommended for most installations. After placing the unit in the desired location and orientation, secure the housing with the optional pipe mounting hardware or other appropriate fasteners.

The IPH² or IPX² will operate when installed at any angle–either surface-mounted or attached to pipe or round conduit. However, there are other considerations in selecting the ideal mounting position. If the IPH² is in an area which may be exposed to rain or water, it should be mounted within 45° of vertical. In natural gas applications, where liquid remnants are possible in the supply, the vent port of the IPX² needs to be in a position that would allow for sufficient draining. Please also consider the requirements in Pneumatics Connections on the next page before determining the ideal mounting configuration.

Phase Two: Electrical Connections

To complete the electrical connections, route the wiring through the conduit port to the terminal block, then use a screwdriver to loosen the terminal screws. (Not necessary for IPX² –NG1 or -NG2 installation.)

For all units except the IPX² –NG1 or –NG2, connect positive lead (+) to the +PS terminal, and negative lead (–) to the –PS terminal. Tighten the terminal screws until snug.

Caution:

When connecting the IPX² Natural Gas (–NG1 or –NG2) model, use an appropriately certified conduit box and wire connectors. Do not attempt to remove the seal fitting, as it is necessary for natural gas certification. Connect the positive lead (+) to the red wire from the seal fitting, and the negative lead (–) to the black wire from the seal fitting. Use shielded, twisted-pair wiring for low-level input. Ground the shielding wire as close as possible to the installed unit.

Recommended Ground Wiring Practices

Moore Industries recommends the following ground wiring practices:

- Any Moore Industries product in a metal case or housing should be grounded.
- The protective earth conductor must be connected to a system safety earth ground before making other connections.
- All input signals to, and output signals from, Moore Industries' products should be wired using a shielded, twisted pair wiring technique. Shields should be connected to an earth or safety ground.
- For the best shielding, the shield should be run all the way from the signal source to the receiving device. (see Note below)
- The maximum length of unshielded input and output signal wiring should be 2 inches.

<u>Note:</u>

Some of Moore Industries' instruments can be classified as receivers (IPT², IPX², etc.) and some can be classified as transmitters (TRX, TRY, etc.) while some are both a receiver and a transmitter (SPA², HIM, etc). Hence, your shield ground connections should be appropriate for the type of signal line being shielded. The shield should be grounded at the receiver and not at the signal source.

CE Conformity

Installation of any Moore Industries' products that carry the CE marking must adhere to the guidelines in the Recommended Ground Wiring Practices section in order to meet the EN 61326 requirements set forth in the applicable EMC directive.

10



Phase Three: Pneumatic Connections

To complete the final phase of installation, connect the supply line to the $\frac{1}{4}$ -inch NPT female port labeled "IN". Connect the output line to the $\frac{1}{4}$ -inch NPT female port labeled "OUT". All tubing must have at least 6mm ($\frac{1}{4}$ -inch) inside diameter or the maximum flow will be limited.

Note:

Seal all fittings with Teflon[®] tape, or equivalent. Always "blow down" (purge) all tubing and the controlled device before connecting the IPH² or IPX².

Manual Override Screw

If you are in a potentially explosive environment and do not want to apply electric power to the unit with the cover removed, the pneumatic installation may be tested by loosening the manual override screw on the bottom of the unit. The output pressure will go to the supply pressure. Be sure to tighten the manual override screw after test.

WARNING:

IPX² units installed in a natural gas application **must** have the natural gas vent properly connected. Follow the directions below to install an IPX² with –NG1 or –NG2 options into a natural gas application.

Natural Gas Applications

Customers using the IPX² with –NG1 or –NG2 options to regulate a sweet natural gas application (H_2 S levels are not to exceed 20ppm) must also make the vent port connections. Connect the Natural Gas Vent (shown in Figure 1) to a device prepared to receive natural gas. After connection, the fittings, cover, and filter/test screw should be tested for leaks.

For an outdoor system, ventilation should consist of a weather-proofed connection between the transmitter exhaust and a riser, six feet above the transmitter and control valve assembly. The riser should be shepherd-crooked to prevent rain or incident water from accumulating at the base. In accordance with local safety regulation, an in-line flame arrestor should be applied to the riser to prevent flash back to the transmitter from an external, spontaneous flame source.

For an indoor system, ventilation must consist of a leak-proof connection from the exhaust of the transmitter to a process vent. The process vent should already be dedicated for natural gas excursions and should conform to all standards for flaring or after-burn, and flame arrest, as dictated by local environmental and safety regulations. Indoor natural gas operations are typically monitored to maintain safety conformance outside the lower and upper explosion limits (LEL and UEL). To add a natural gas operated transmitter in these cases, consideration should be made as to the extent of natural gas leak detection legacy to the installed transmitter. Placement of the transmitter should be such that detection and alarming surround any critical connections between the transmitter and the natural gas process.

If the natural gas driven transmitter is to be installed indoors with no legacy monitoring capabilities, additional consideration must be made to ensure the operating area is well-ventilated and the transmitter can be exhausted to process vent. Furthermore, monitoring with remote annunciation within LEL and UEL should be projected as an upgrade to the facility, concurrently with this installation. The transmitter installation must adhere to local environmental and safety regulations.

WARNING:

IPX² units installed in a natural gas application must have the natural gas vent properly connected. Failure to do so may result in an explosion. The –FR1 option should not be used with a flammable gas because it has a vent to atmosphere. A filter-regulator without a vent may be used. For natural gas certification to be valid, the vent system must be able to maintain <1psig.

Filters. The IPH² and IPX² requires filtered, dry, regulated, instrument-quality air to prevent clogging and to ensure extended periods of maintenance-free operation. Moore Industries suggests the following levels of filtering protection:

- Pre-filter A general purpose "rough" filter, used to reduce particulate matter to 5 microns in size. Also removes bulk liquids. Although not required, this filter is especially recommended to protect the 0.01 micron final filter when used.
- Final Filter A second, final filter is recommended to remove particulate matter in sizes down to 0.01 micron. This filter removes virtually all condensable liquids from the air stream as well.
- Filter/Regulator Module Option A combined filter/regulator assembly, the -FR1 Option, offered as an accessory for either the IPH² or IPX², removes particles down to 0.01 microns, supplying regulated, instrument-quality air to the unit. This space-saving module is affixed to the supply port, and comes with a pressure gauge scaled in both psi (0-60) and Bars (0-4).

Hazardous Location Applications

This section contains important information regarding installation of IPX² in hazardous locations.

Classification of the area and installation of the IPX² should be done in accordance with applicable electrical codes such as the United States National Electrical Code (NEC), and/or any other equivalent/ applicable internationally adopted standards and installation codes (CEC & IEC).

Refer to the Special Conditions outlined below before proceeding with installation.

Safety Concerns

For your safety, read the following information carefully before proceeding with installation.

WARNING:

EXPLOSION HAZARD – For Division 2 Hazardous locations. DO NOT

Disconnect equipment when a flammable atmosphere is present.

WARNING:

Substitution of components is not allowed, as it may impair the intrinsic safety (Zones 0 & 1, Division 1) of the unit and/or the non-incendive/Type N (Division 2, Zone 2) circuit. **DO NOT** open the unit when either energized or when an explosive gas/dust atmosphere is present. Disconnect power before servicing. Read and understand the Manufacturer's installation and Operating procedures, and adhere to all applicable electrical codes, safety instructions and regulations.

Avertissement:

Ouvrir le circuit avant d'enlever le couvercle. La substitution de composants peut compromettre la sécurité intrinséque. Un scellement doit être installé à moins de 457mm du boîtier. En Classe 1, Division 2, ce produit doit être installé conformément 170-775-00.

Special Conditions of Use

The following instructions must be adhered to when the Model IPX² is used in hazardous locations and potentially explosive atmospheres.

cCSAus Installations

Intrinsically Safe Applications

Class I, Div. 1 & 2, Groups A, B, C & D Class II & III, Div 1 & 2, Groups E, F, & G Class1, Zone 0, AEx ia IIC, Ex ia IIC

The Model IPX² shall be supplied by a Class 2 or SELV Limited Circuit as defined by CAN/CSA # 1010.1 Annexes F.2.1 and H.

The Model IPX² must be installed by drawing 100-100-78.

Explosion/Flame Proof Applications

Class I, Division 1, Groups A, B, C & D Class II & III, Div 1 & 2, Groups E, F, & G Class I, Zone 1, AEx d IIC, Ex d IIC

The Model IPX² shall be supplied by a Class 2 or SELV Limited Circuit as defined by CAN/CSA # 1010.1 Annexes F.2.1 and H.

Nonincendive, Type n Applications

Class I, Division 2, Groups A B, C & D Class1, Zone 2, AEx nA IIC, Ex nA IIC

The Model IPX² shall be supplied by a Class 2 or SELV Limited Circuit as defined by CAN/CSA # 1010.1 Annexes F.2.1 and H.

Installation of Model IPX² with the –NG Option in a Class I, Division 2 classified area requires the use of wiring and venting methods applicable for Class I, Division 1 Hazardous 'Classified' Locations. Venting the IPX² with the –NG Option to an approved continuous ignition flare system, or to a Class I, Division 1 Hazardous 'Classified' Area which provides minimum back-pressure to the device, must be utilized. Vent piping and electrical conduits must be designed and installed using approved good engineering practices.



European Union Installations

(ATEX 2014/34/EU Directive)

Intrinsically Safe Applications - Zone 0 II 1 G Ex ia IIC T4 Ga

The enclosure is manufactured from 6063-T5 Aluminum alloy. In rare cases, ignition sources due to impact and friction sparks could occur. This shall be considered during installation, particularly if the equipment is installed in a Zone 0 location.

The IPX² has the following safety parameters when input terminals are connected to a linear, resistive barrier:

Ui = 30Vdc, li = 110mA, Pi = 0.825W, Ci = 720pF, Li = 5.12μ H.

The IPX² is to be installed per Field Installation Drawing, 100-100-78.

Flame Proof Applications - Zone 1

II 2 G Ex d IIC T4 Gb II 2 D Ex tb IIIC T127°C Db

The stopping plugs must not be used with a thread adapter/reducer.

Model IPX 2 with the –NG Option (Natural Gas as the input medium) is excluded.

Type n Applications - Zone 2

II 3 G Ex nA IIC

On installation, the Model IPX² shall be provided with supply transient protection external to the apparatus such that the voltage at the supply terminals of the IPX² does not exceed 119V peak or 119Vdc.

Model IPX² with the –NG Option (Natural Gas as the input medium) is excluded.

Australia New Zealand ANZEx Installations

When the apparatus is used in a Zone 0 environment it is a condition of safe use that the apparatus shall

be protected from impact.

Intrinsically Safe Applications Certificate No.: ANZEx 09.3000X

Standards: AS/NZS 60079.0:2005 Explosive atmospheres -Equipment - General requirements

AS/NZS 60079.11:2006 Explosive atmospheres - Equipment protection by intrinsic safety 'i'

Type n Applications

Certificate No.: ANZEx 09.3000X

Standards: AS/NZS 60079.0:2005 Explosive atmospheres -Equipment - General requirements

AS/NZS 60079.15:2006 Explosive atmospheres -Equipment protection by type of protection 'n'

Operation

Once the unit has been configured and installed, it operates unattended with the exception of the minor maintenance procedures that are described in the next section.

If the unit is determined to be the cause of a loop irregularity, carry out the maintenance procedure in the next section of this manual. If problems persist, refer to the Troubleshooting Section.

Instrument-quality Air. Air from the application continuously flows through the IPH²/IPX² during operation. Depending upon the purity of the air supply, the unit's internal assembly may have to be removed and cleaned to ensure continued optimum performance.

Initially, random checks can help establish a satisfactory internal maintenance geared to the user's air supply cleanliness. Refer to the next section for instruction on the disassembly and cleaning of your unit.

Maintenance

For most applications, no maintenance outside of routine inspection and calibration of the IPH² or IPX² will be necessary. These units are designed to work unattended for up to six months with little change in accuracy.

Troubleshooting the IPH² & IPX²

If a problem is suspected with the IPH² or IPX², review the following steps:

- Verify that bench instruments used to take measurements have the proper range and accuracy and are within current certification period limits.
- 2. If a change in the relationship between the input and output is detected, attempt a re-calibration of the unit.
- If the response time lengthens, or if the span drops, check the system for a blockage due to air supply contamination. Please refer to Maintenance section for details of replacing filters, electronic modules and drain checking.

If the unit needs to be returned for service, the complete valve assembly can be removed from the housing for replacement without disturbing the connections to the housing. Contact customer service for details.

Drain Check

System filters (not IPX²/IPH² filters) have automatic drains that depend on the fluctuation of system pressure to induce drainage. A stable system may not drain efficiently. Check periodically for clogs and drain system's filters by pushing the drainage valve with a small probe or wire.

IPX² Replacement Modules*


*This applies only to new versions of the IPX² introduced in 2013.

In abnormal operating conditions in which a slug (liquid) is present in the IPX² air/ gas supply, the electronic module may be removed. This can help in

the recovery of the unit, by allowing any accumulated liquid to drain out more effectively. To remove the module follow these steps:


 Use a 3mm Allen wrench to unlock the cover. Drive the Allen screws clockwise until the cover is allowed to rotate freely. Remove the cover by accessing the locking screw shown in Figure 6.

Figure 6. Unlocking the IPX² Cover



2. Use a Phillips head screw driver to remove the four module mounting screws shown in Figure 7.


Figure 7. Removing Mounting Screws



 Carefully, pull the module from the housing. The pneumatic stem, found on the bottom of the module, is fragile; handle with care. See Figure 8.



Figure 8. Removing Module from Housing



 Item
 P/N
 Description
 Qty

 ①
 208-876-00
 Module
 1


- 4. Inspect the module and the barrier plate for any signs of contamination. Remove any excess liquid and allow to dry before replacing. The electronic module is not field-serviceable. If irreparable damage is found, it may be replaced. See Data Sheet for ordering information.
- 5. To re-assemble, replace the module using locating pins (see step 3), tighten the 4 module screws (see step 2), replace the cover and secure with the locking screw (step 1).
- 6. Recalibrate the unit before returning to service. Refer to the Calibration Section of this manual for instructions.

Customer Service


Moore Industries is recognized as the industry leader in delivering top quality to its customers in products and services. We perform a battery of stringent quality assurance checks on every unit we ship. If any Moore Industries product fails to perform up to rated specifications, call us for help. Our highly skilled staff of trained technicians and engineers pride themselves on their ability to provide timely, accurate and practical answers to your process instrumentation questions.

Factory phone numbers are listed on the back cover of this manual.

If problems involve a particular IPH²/IPX², there are several pieces of information that can be gathered **before you call the factory** that will help our staff get the answers you need **in the shortest time possible**. For fastest service, gather the complete model and serial number(s) of the problem unit(s) and the job number of the original sale.







	~ □		ר הה ה -	
- WARNIG - Substitution of components may impair Intrinsic Safety. To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing.	 The Entity Concept allows interconnection of associated apparatus and intrinsically safe apparatus when the following is true: Uo ≤ Ui , Io ≤ II , Po ≤ Pi , Co Ci + Ccable; Lo Li + Lcable. No revision is allowed to this drawing without prior SIRA Approval. 	 Installations in the U.S. shall be in accordance with ANSI/ISA KP12.06.01 "Installation of Intrinsically Safe Systems for Hazardous (Classified) Locations" and the latest edition of the National Electrical Code (ANSI/NFPA 70). Resistance between Intrinsically Safe Ground and earth ground must be less than 1.0 Ohm. Installation in Canada shall be in accordance with the latest edition of the C22.1 Canadian Electrical Code, Part I. Installation in Europe shall be in accordance with the latest editions of the wiring practices for the country of origin and EN 60079-14. 	ā	Image: Normal state
		Installation may only be carried out by suitably trained personnel and in accordance with national wiring regulations or codes of practice.	Where English is not a language of the Country in which the equipment is being used, please apply to Moore Industries International, Inc. (MII) for a suitable translation.	DRAWING NUMBER 100-100-78 SHEET 3 of 3 REVISION REVISED BY SHEET 3 OATE BY APPROVAL SEE SHEET 1 DATE BY APPROVAL NOTICE RE PROPRIETARY INFORMATION: This drawing and the information contained herein are the proprietary property of Moore Industries International, Inc. (MII) and should not be reproduced or disclosed to any third party without the written consent of an authorized officer of MII.

Certified Product This is a controlled 'Related' or 'Schedule' drawing. No modifications are permitted without the notification and final approval of the Certification Engineer (related dwgs.) or the Certifying Agency (schedule dwgs.)

IPH² & IPX²

Current-to-Pressure (I/P) Transmitters

RETURN PROCEDURES

To return equipment to Moore Industries for repair, follow these four steps:

1. Call Moore Industries and request a Returned Material Authorization (RMA) number.

Warranty Repair –

If you are unsure if your unit is still under warranty, we can use the unit's serial number to verify the warranty status for you over the phone. Be sure to include the RMA number on all documentation.

Non-Warranty Repair –

If your unit is out of warranty, be prepared to give us a Purchase Order number when you call. In most cases, we will be able to quote you the repair costs at that time. The repair price you are quoted will be a "Not To Exceed" price, which means that the actual repair costs may be less than the quote. Be sure to include the RMA number on all documentation.

- 2. Provide us with the following documentation:
 - a) A note listing the symptoms that indicate the unit needs repair
 - b) Complete shipping information for return of the equipment after repair
 - c) The name and phone number of the person to contact if questions arise at the factory
- Use sufficient packing material and carefully pack the equipment in a sturdy shipping con-3. tainer.
- Ship the equipment to the Moore Industries location nearest you. 4.

The returned equipment will be inspected and tested at the factory. A Moore Industries representative will contact the person designated on your documentation if more information is needed. The repaired equipment, or its replacement, will be returned to you in accordance with the shipping instructions furnished in your documentation.

WARRANTY DISCLAIMER

THE COMPANY MAKES NO EXPRESS, IMPLIED OR STATUTORY WAR-RANTIES (INCLUDING ANY WARRANTY OF MERCHANTABILITY OR OF FITNESS FOR A PARTICULAR PURPOSE) WITH RESPECT TO ANY GOODS OR SERVICES SOLD BY THE COMPANY. THE COMPANY DIS-CLAIMS ALL WARRANTIES ARISING FROM ANY COURSE OF DEALING OR TRADE USAGE, AND ANY BUYER OF GOODS OR SERVICES FROM THE COMPANY ACKNOWLEDGES THAT THERE ARE NO WARRANTIES IMPLIED BY CUSTOM OR USAGE IN THE TRADE OF THE BUYER AND OF THE COMPANY, AND THAT ANY PRIOR DEALINGS OF THE BUYER WITH THE COMPANY DO NOT IMPLY THAT THE COMPANY WARRANTS THE GOODS OR SERVICES IN ANY WAY.

ANY BUYER OF GOODS OR SERVICES FROM THE COMPANY AGREES WITH THE COMPANY THAT THE SOLE AND EXCLUSIVE REM-EDIES FOR BREACH OF ANY WARRANTY CONCERNING THE GOODS OR SERVICES SHALL BE FOR THE COMPANY, AT ITS OPTION, TO REPAIR OR REPLACE THE GOODS OR SERVICES OR REFUND THE PURCHASE PRICE. THE COMPANY SHALL IN NO EVENT BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES EVEN IF THE COMPANY FAILS IN ANY ATTEMPT TO REMEDY DEFECTS IN THE GOODS OR SERVICES, BUT IN SUCH CASE THE BUYER SHALL BE ENTITLED TO NO MORE THAN A REFUND OF ALL MONIES PAID TO THE COMPANY BY THE BUYER FOR PURCHASE OF THE GOODS OR SERVICES.

ANY CAUSE OF ACTION FOR BREACH OF ANY WARRANTY BY THE COMPANY SHALL BE BARRED UNLESS THE COMPANY RE-CEIVES FROM THE BUYER A WRITTEN NOTICE OF THE ALLEGED DEFECT OR BREACH WITHIN TEN DAYS FROM THE EARLIEST DATE ON WHICH THE BUYER COULD REASONABLY HAVE DISCOVERED THE ALLEGED DEFECT OR BREACH, AND NO ACTION FOR THE BREACH OF ANY WARRANTY SHALL BE COMMENCED BY THE BUYER ANY LATER THAN TWELVE MONTHS FROM THE EARLIEST DATE ON WHICH THE BUYER COULD REASONABLY HAVE DISCOV-ERED THE ALLEGED DEFECT OR BREACH.

RETURN POLICY

For a period of thirty-six (36) months from the date of shipment, and under normal conditions of use and service, Moore Industries ("The Company") will at its option replace, repair or refund the purchase price for any of its manufactured products found, upon return to the Company (transportation charges prepaid and otherwise in accordance with the return procedures established by The Company), to be defective in material or workmanship. This policy extends to the original Buyer only and not to Buyer's customers or the users of Buyer's products, unless Buyer is an engineering contractor in which case the policy shall extend to Buyer's immediate customer only. This policy shall not apply if the product has been subject to alteration, misuse, accident, neglect or improper application, installation, or operation. THE COMPANY SHALL IN NO EVENT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES

www.miinet.com

BeNeLux • info@mooreind.eu



United States • info@miinet.com Tel: (818) 894-7111 • FAX: (818) 891-2816 Australia • sales@mooreind.com.au Tel: (02)8536-7200 • FAX: (02) 9525-7296 Tel: 03/448.10.18 • FAX: 03/440.17.97

- Demand Moore Reliability -China • sales@mooreind.sh.cn Tel: 86-21-62491499 • FAX: 86-21-62490635 United Kingdom • sales@mooreind.com Tel: 01293 514488 • FAX: 01293 387752