

No .206-785-00E August 2019



4 -Wire, 2-Channel Signal Isolator/Convertor

MIT



User's Manual

All product names are registered trademarks of their respective companies.



Demand Moore Reliability

Customer Support

Moore Industries is recognized as the industry leader in delivering top quality to its customers in products and services. We perform a sequence of stringent quality assurance checks on every unit we ship. If any Moore Industries product fails to perform up to rated specifications, call us for help. Our highly skilled staff of trained technicians and engineers pride themselves on their ability to provide timely, accurate, and practical answers to your process instrumentation questions. Our headquarters and other facilities phone numbers are listed below.

There are several pieces of information that can be gathered before you call the factory that will help our staff get the answers you need in the shortest time possible. For fastest service, gather the complete model and serial number(s) of the problem unit(s) and the job number of the original sale.

Locations

World Headquarters

16650 Schoenborn Street North Hills, California 91343-6196, **U.S.A.** Tel: (818) 894-7111

Fax: (818) 891-2816 E-mail: info@miinet.com TOLL FREE: 1-800-999-2900

www.miinet.com

China

Room 402, No. 57, Lane 651, Xipu Road, Xinqiao Town, Songjiang District, **Shanghai**, 201612, P. R. China Tel: 86-21 62491499

Fax: 86-21 62490635

E-mail: sales@mooreind.sh.cn

Europe

1 Lloyds Court, Manor Royal, Crawley W. Sussex RH10-9QU **United Kingdom** Tel: 01293 514488 Fax: 01293 536852

FREE PHONE: 0800 525107 sales@mooreind.com

BeNeLux

Guido Gezellestraat 106 BE-2630 Aartselaar **Belgium**

Tel: 03/448.10.18 Fax: 03/440.17.97 info@mooreind.eu

Australia

Sydney, NSW 3/1 Resolution Drive Caringbah, New South Wales 2229 **Australia**

Tel: (02) 8536-7200 Fax: (02) 9525-7296 sales@mooreind.com.au

Perth, WA 6/46 Angove Street North Perth, Western Australia 6006 Australia

Tel: (08) 9228-4435 Fax: (08) 9228-4436 sales@mooreind.com.au



www.miinet.com

Table of Contents

Introduction	4
About this Manual	4
Model and Serial Numbers	4
Inputs and Ouputs	4
Specifications	5
Dimensions	5
Accessories	6
Docking Clamping Tool and Loop ID Location	6
Wire Termination	6
Wire Installation	6
Calibration	7
Calibration Setup	7
Calibration Procedure	7
Installation	8
Recommended Ground Wiring Practices	8
CE Conformity	8
Installations in Hazardous Locations	8
Specific Conditions of Use	9
Electrical Connections	9
Installation Category	9
Equipment Ratings	9
Supply Wiring	9
Mounting	10
Cleaning and Maintenance	10
Replacement of Consumable Materials	10
Customer Support	10
Symbols	10
Warranty	11

4-Wire, 2-Channel Signal Isolator/Convertor

Introduction

This is the users' manual for Moore Industries' miniMOORE MIT 4-Wire, 2-Channel Signal Isolator/ Convertor. The MIT is powered by a universal power supply and provides 1000Vrms input-to-output, channel-to-channel isolation, and signal isolation between two non-isolated transmitters and a receiving device. This eliminates faulty readings in process measurements caused by ground loops, motor noise, and other unpredictable electrical interference.

The MIT provides two individual channels with user selectable inputs and two 4-20mA outputs ready for direct interface with a receiving device.

About this Manual

Wherever you see a "*WARNING*", "*Caution*" or "*Note*" pay particular attention.

<u>WARNING</u> - Hazardous procedure or condition that could injure the operator.

<u>Caution</u> - Hazardous procedure or condition that could damage or destroy the unit.

Note - Information that is helpful for a procedure, condition, or operation of the unit.

Model and Serial Numbers

Moore Industries uses a system of model and serial numbers to keep track of all of the information on every unit it sells and services. If a problem occurs with your MIT, check for a tag affixed to the unit listing these numbers. Supply the Customer Support representative with this information when calling.

Inputs and Ouputs

The 4-wire, 2-channel MIT has two independent switch configurable inputs 4-20mA, 1-5V, 0-5V, or 0-10V with two corresponding isolated 4-20mA outputs. Switch selectable inputs are accessible on side of unit. (See Figures 1 and 2). The front panel of unit has two adjustments per channel, Zero (±5%) and Span (±10%) pot for adjustment as needed.

Figure 1. The MIT has two user selectable inputs and two 4-20mA outputs





Figure 2. Settings for Channels A and B input ranges





Specifications

4-Wire, 2-Channel Universal Powered Isolator							
Performance	Accuracy: ±0.1% of span (includes input accuracy, output accuracy, and the combined effects of linearity, hysteresis and repeatability) Stability: ±0.2% of reading per year Isolation: 1000Vrms between inputs and outputs and channel to channel; 2500Vrms between power supply	Performance (continued)	Power Supply Effect: <0.05% of Span Maximum Input Over Range: Current inputs, 100mA maximum Voltage inputs, 150% of full scale Burden: 1V maximum for current; 1Mohms minimum for voltage Load Capacity: 600ohms max.	Conditions	±0.015% of span/°C maximum Relative Humidity: 0-95% non-condensing RFI/EMI Protection: 80%AM at 1KHz, 10V/m@ 20-1000MHz per IEC61000-4-3 Common Mode Rejection: Exceeds 95dB@60Hz with a limit of 500Vrms		
	and input, and power supply and output Output Response Time: 100msec maximum to 99% of output; 50 msec to	Ambient	Output Current Limiting: 25mA typical; 30mA maximum Operating Range:	Adjustments	Type: Front panel potentiometers Span: ±10% Zero: ±5% (non-interactive when		
	90% output change DC Input Resistance:	Conditions	-40°C to +70°C (-40°F to +158°F)		span is set first)		
	50 ohms for current; 1 Mohm for voltage Ripple: <10mV peak-to-		Storage Range: -40°C to +85°C	Power Supply	Universal: 20-125VDC, 90-250VAC		
	peak maximum measured across a 250 ohm resistor Over-Voltage Protection:		(-40°F to +185°F) Ambient Temperature		AC, 2W, 4VA max; DC, 2.6W, 24VDC		
	30V reverse polarity protection on output		Effect: ±0.007% of span/°C typical;	Weight	263 g (9.3 oz)		

Dimensions

Figure 3. Aluminum-housed 4-wire, 2-channel MIT dimensions





Accessories

Your mini**MOORE** MIX unit comes with the following accessories:

Figure 4. MIT miniMOORE accessories

miniMOORE User Manuals on CD


miniMOORE Quick Set-Up Guide

Interface Solution Configuration Tools and Installation Manuals

miniMOORE Quick Set-Up Guide

m






Clamping Tool (Used with Type A Connectors)



Docking Clamping Tool and Loop ID Label Location

Figure 5 below illustrates proper location to dock clamping tool after use and correct location for the Loop ID label.

Figure 5. MIT miniMOORE accessories



Wire Termination

Refer to Figure 1 for wire termination for your MIX unit.


Wire Installation

The connectors must be removed from unit, to properly install wires in each of the connectors.

Figure 6 below, illustrates how to use the wiring clamp tool to correctly install the wire into connector. Insert clamp in proper slot and press downward, this will momentarily open terminal slot. Slide wire into place, and then release pressure on clamp tool to lock wire in place.

After correct wiring, following the wire termination shown in Figure 1, place connector back onto unit. Refer to Figure 5 for proper storage of clamping tool.

Figure 6. Using the clamping tool



Calibration

Before placing your MIT into service, a bench check of basic operation is recommended to ensure that the unit hasn't sustained any damage during transit, and to set zero and span for your application.

Every unit should be:

- Checked to verify that the appropriate MIT model has been ordered for the intended application.
- Connected in a calibration setup (described later in this section) and checked for desired output.
- · Adjusted for desired zero and span settings.

Calibration Setup

Table 1 lists the equipment you will need to bench check the MIT. These materials are not supplied by Moore Industries, but should be available in environments suited for calibration and maintenance of electronic instruments.

Figure 7 shows the calibration setup for the 4-wire, 2-channel MIT.

Table 1. Equipment for MIT calibration

Device	Specification	
Current or Voltage Calibrator	Adjustable, calibrated to an accuracy of ±0.025% (EDC Model CR 103 or MV 105, or equivalent)	
Power Supply	20-125VDC, 90-250VAC	
Load Resistor	250 ohms (±0.01%) precision	
Multimeter	Calibrated to an accuracy of ±0.025%, minimum (Keithley Model 197, or Fluke Model 8840 or 8842, or equivalent)	
Screwdriver	Standard (Blade-type), head width 2.5mm (0.10 in), maximum	

Calibration Procedure

With the unit incorporated into the appropriate setup (as illustrated in Figure 7):

- 1. Apply the appropriate power to the "PS" side of the setup.
- 2. Set the source calibrator to 0% of the rated span for the type of MIT being calibrated.


For example, 4mA for a 4-20mA input unit.

- 3. Adjust the MIT Zero potentiometer (pot) until the voltmeter in the setup reads 1V plus/minus the stated accuracy specification.
- 4. Set the calibrator to 100% of the rated span (full scale) of MIT being calibrated.

For example, 20mA for a 4-20mA input unit.

- Adjust the span potentiometer (pot) until the voltmeter reads 5V plus/minus the stated accuracy specification across the precision resistor.
- 6. Repeat steps 2 through 5 until the voltage across the resistor is stable and within rated unit accuracy at both 0% and 100% of span.
- Move the calibrator and power source to the next channel and repeat steps 1 through 6 for the remaining channels of the 4-wire, 2-channel MIT unit.

Figure 7. Calibrating the 4-wire, 2-channel MIT




5 250 €

90-250VAC


Installation

Figure 3 on page 4 shows the physical dimensions of the MIT. To install the MIT on a DIN-rail, set the appropriate lip on the back of the unit on the top edge of the DIN-rail and pivot downward until the unit snaps into place.

Figure 8 Installing the 4-wire, 2-channel MIT



BOTTOM VIEW



Recommended Ground Wiring Practices

Moore Industries recommends the following ground wiring practices:

- Any Moore Industries product in a metal case, enclosure or housing should be grounded.
- The protective earth conductor must be connected to a system safety earth ground before making other connections.
- All input signals to, and output signals from, Moore Industries' products should be wired using a shielded, twisted pair wiring technique. Shields should be connected to an earth or safety ground.

- For the best shielding, the shield should be run all the way from the signal source to the receiving device. (see Note below)
- The maximum length of unshielded input and output signal wiring should be 2 inches.

Note - Some of Moore Industries' instruments can be classified as receivers (IPT2, IPX2, etc.) and some can be classified as transmitters (TRX, TRY, etc.) while some are both a receiver and a transmitter (SPA2, HIM, etc). Hence, your shield ground connections should be appropriate for the type of signal line being shielded. The shield should be grounded at the receiver and not at the signal source.

CE Conformity

Installation of Moore Industries' products that carry CE marking must adhere to:

The guidelines in the Recommended Ground Wiring Practices section in order to meet the requirements in EN 61326 and the relevant EMC directive.

The guidelines in the Supply Wiring section and requirements in EN61010-1 and the relevant Low Voltage Directive.

Installation in Hazardous Locations

This section contains important information regarding installation of the MIT 4 wire 2 channel in Hazardous Area locations.

Note - The MIT 4 wire 2 channel is suitable for Class I. Division 2, Groups A-D or General Locations only.

WARNING:

Do not disconnect equipment when a flammable or combustible atmosphere is present.

Specific Conditions of Use

The following instructions must be adhered to when the MIT 4 wire 2 channel is used in hazardous locations and potentially explosive atmospheres.

The MIT 4 wire 2 channel shall be installed in compliance with the enclosure, mounting, spacing and segregation requirements of the ultimate application.

cCSAus Installation
Nonincendive Applications
Class I, Division 2, Groups A-D
Electronic components must be mounted in a suitable enclosure.

Electrical Connections

Figure 8 illustrates the proper hookup for correctly installing an MIT into your process.

WARNING:

If this unit is used in a manner not specified by Moore Industries, the protection provided by the equipment may be impaired.

Equipment Ratings

Moore Industries transmitters do not generate hazardous voltages. They measure voltage or current inputs, and generate low voltages and currents (<42Vdc and <25mAdc). Products connected to Moore Industries transmitters should be designed to receive these inputs.

Switches and Circuit Breakers

For SST AC powered units, a switch or circuit breaker must be wired in series with the AC power conductors. The switch or circuit breaker used must be located within three meters of the unit.

The circuit breaker or switch will only remove power to the unit, hazardous voltages may still be connected to other terminals on the unit.

117Vac, 230Vac, and 24Vdc Supply Wiring

All power connections should be made with 14 or 16 AWG (2mm2 or 1.3mm2) wire.

The end of each conductor should be stripped no more than 0.25in (7mm). The end of the stripped wire should be tinned with solder, or inserted into a ferrule and crimped before being placed into a terminal block.

Tighten the screws on the terminal block to 4.4 - 5.3 lbf•in (0.5 - 0.6 N•m)

Supply Wiring

All power connections shall be made with 16 to 20 AWG wire.



Mounting

When mounting the unit or installing it into an application, ensure that the unit can be easily removed for maintenance or repairs.

Cleaning and Maintenance

Maintenance on Moore Industries' products is limited to keeping the unit clean and the wire terminals free of oxidation. This is best accomplished by installing the unit in an area protected from dust, heat, moisture, and corrosive atmospheres. Yearly visual inspections should be performed to ensure that the unit is clean and the electrical connections are in good repair.

Replacement of Consumable Materials

No consumable materials are used in the Moore Industries products covered by EN 61010-1.

Customer Support

Recognized as the industry leader for delivering top quality products and services to our customers, Moore Industries is dedicated to quality. If any product fails to perform up to rated specifications, call us for help. Our team of technicians and engineers will provide timely, accurate, and practical answers to your process instrumentation questions.

If problems involve a particular MIT, there are several pieces of information you can gather before you call the factory that will help our staff get your answers more efficiently. When you call, please have:

- · The model number of the unit in question
- The serial number of the unit in question
- The job number (if available)
- The purchase order under which the unit was shipped (if available)

Factory contact information is on the back cover.

Symbols

Table 2 shows the symbols used on Moore Industries' products, the corresponding IEC/ISO symbol, and its definition.

Table 2. Symbols on Moore Industries' Products

IEC/ISO Symbol	Symbol on Moore Industries Product	Definition	
	+PS -PS DCC	Direct Current	
\sim	AC ACC	Alternating Current	
$\overline{\sim}$	C or DC	Direct and Alternating Current	
<u></u>	GND	Protected Earth Terminal	
		Protective Conductor Terminal	
	<i>9</i> 1	Equipment protected throughout by double insulation or reinforced insulation (equivalent to Class II of IEC 536)	
	<u></u>	Caution (See manual for information)	
Not Specified	+INPUT -INPUT	Positive Input Negative Input	
Not Specified	+OUTPUT -OUTPUT	Positive Output Negative Output	
Not Specified	NO NC CM	Normally Open Normally Closed Common	
Not Specified	UNO UNC	Upper Normally Open Upper Normally Closed	
Not Specified	LNO	Lower Normally Open Lower Normally Closed	
	LNC	Lower Normally Closed	

Warranty Disclaimer

Moore Industries ("The Company") makes no express, implied or statutory warranties (including any warranty of merchantability or of fitness for a particular purpose) with respect to any goods or services sold by the company. The company disclaims all warranties arising from any course of dealing or trade usage, and any buyer of goods or services from the company acknowledges that there are no warranties implied by custom or usage in the trade of the buyer and of the company, and that any prior dealings of the buyer with the company do not imply that the company warrants the goods or services in any way.

Any buyer of goods or services from the company agrees with the company that the sole and exclusive remedies for breach of any warranty concerning the goods or services shall be for the company, at its option, to repair or replace the goods or services or refund the purchase price. The company shall in no event be liable for any consequential or incidental damages even if the company fails in any attempt to remedy defects in the goods or services, but in such case the buyer shall be entitled to no more than a refund of all monies paid to the company by the buyer for purchase of the goods or services.

Any cause of action for breach of any warranty by the company shall be barred unless the company receives from the buyer a written notice of the alleged defect or breach within ten days from the earliest date on which the buyer could reasonably have discovered the alleged defect or breach, and no action for the breach of any warranty shall be commenced by the buyer any later than twelve months from the earliest date on which the buyer could reasonably have discovered the alleged defect or breach.

Return Policy

For a period of thirty-six (36) months from the date of shipment, and under normal conditions of use and service, Moore Industries ("The Company") will at its option replace, repair or refund the purchase price for any of its manufactured products found, upon return to the Company (transportation charges prepaid and otherwise in accordance with the return procedures established by The Company), to be defective in material or workmanship. This policy extends to the original Buyer only and not to Buyer's customers or the users of Buyer's products, unless Buyer is an engineering contractor in which case the policy shall extend to Buyer's immediate customer only. This policy shall not apply if the product has been subject to alteration, misuse, accident, neglect or improper application, installation, or operation. THE COMPANY SHALL IN NO EVENT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.

To return equipment to Moore Industries for repair, follow these four steps:

1. Call Moore Industries and request a Returned Material Authorization (RMA) number.

Warranty Repair -

If you are unsure if your unit is still under warranty, we can use the unit's serial number to verify the warranty status for you over the phone. Be sure to include the RMA number on all documentation.

Non-Warranty Repair -

If your unit is out of warranty, be prepared to give us a Purchase Order number when you call. In most cases, we will be able to quote you the repair costs at that time. The repair price you are quoted will be a "Not To Exceed" price, which means that the actual repair costs may be less than the quote. Be sure to include the RMA number on all documentation

- Provide us with the following documentation:
 - a) A note listing the symptoms that indicate the unit needs repair
 - b) Complete shipping information for return of the equipment after repair
 - c) The name and phone number of the person to contact if guestions arise at the factory
- 3. Use sufficient packing material and carefully pack the equipment in a sturdy shipping container.
- Ship the equipment to the Moore Industries location nearest you.

The returned equipment will be inspected and tested at the factory. A Moore Industries representative will contact the person designated on your documentation if more information is needed. The repaired equipment, or its replacement, will be returned to you in accordance with the shipping instructions furnished in your documentation.



- Demand Moore Reliability • www.miinet.com United States . info@miinet.com Tel: (818) 894-7111 . FAX: (818) 891-2816

Austrália • sales@mooreind.com.au Tel: (02) 8536-7200 • FAX: (02) 9525-7296 Tel: 03/448.10.18 • FAX: 03/440.17.97

BeNeLux . info@mooreind.eu

China sales@mooreind.sh.cn Tel: 86-21-62491499 • FAX: 86-21-62490635 United Kingdom . sales@mooreind.com Tel: 01293 514488 • FAX: 01293 536852