

No. 235-731-00K **August 2020** 



### SIY

### **User's Manual**

All product names are registered trademarks of their respective companies.

### **Table of Contents**

Introduction	3
The SIY	3
Specifications	4
Ordering Information	5
SIY Model Numbers-Ordering	6
Configuration & Bench Check	6
Installing the Configuration Software	7
Connecting the SIY to the PC	7
Bench Check Setup	8
Using a PC Configuration Overview	9
Saving the SIY Configuration File to Disk	11
Using a Configuration File already on Disk	11
Loading a Configuration File from a Connected SIY	12
Setting Output Damping	12
Trimming SIY Output	12
Trimming the Input	13
Creating a Custom Linearization Table	14
Installation	16
Mounting and Connections	16
Mounting the HPP-housed SIY	16
Mounting the DIN-housed SIY	16
Electrical Safety Information	16
Dimensions	17
Operation	18
Maintenance	18
Troubleshooting	18
Customer Support	19
Warranty Disclaimer	20
SIY Electrical Safety Manual	

### Introduction

This is the users' manual for Moore Industries' SIY PC-Programmable Signal Isolator/Converter. It contains all of the information that is needed to configure, install, operate, maintain, and troubleshoot the SIY. If you require additional assistance, call one of our STAR Centers (for Service, Technical Assistance, and Repair) to talk with a technician or engineer.

**WARNING** – Hazardous procedure or condition that could injure the operator.

**Caution** - Hazardous procedure or condition that could damage or destroy the unit.

**Note** – Information that is helpful for a procedure, condition, or operation of the unit.


### The SIY

The SIY is a versatile, 2-wire (loop-powered), PC-Programmable Signal Isolator/Converter that accepts a current or voltage input and provides an isolated, proportional 4-20mA output. See Figure 1 for a list of accommodated input types.

Typical uses for the SIY include:

- Isolating Signals to stop erratic process measurements caused by ground loops
- Converting Signals so field instruments can interface directly with indicators, recorders, DCS's, PLC's, and PC-based SCADA systems
- . Diverting Signals so the output from one transmitter can be sent to two separate locations
- Protecting Equipment and Signals by eliminating common electrical paths
- Boosting Signals to enable more instruments to be added to an overburdened loop
- Solving the "Bucking Power Supplies" problem that occurs when a 4-wire transmitter and a DCS both try to power the same process loop

Figure 1. Compact, yet powerful, the SIY transmitter features programmable inputs and a trimmable output to boost accuracy.



### **Specifications**

Performance Accuracy: ±0.08% of span (includes input accuracy, output accuracy, and the combined effects of linearity, hysteresis, repeatability, and adjustment resolution) Minimum Input Span:

Current, 1mA; Voltage, 250mV

Isolation:

HPP housing, 1500Vrms input to output to case; DIN housing, 500Vrms input to output to case

**Measurement Cycle:** Output updates 8 times per second

**Output Response:** 

256msec, maximum (128msec typical) for output to reach full scale response to a 10-90% step change on input

Input Impedance:

Voltage, 1Mohm; Current, 20ohms

Ripple: 10mV peak-topeak maximum (measured across 250ohm resistor)

Load Effect (current outputs): Negligible within specified load limits

(continued)

Perfor- Power Supply Effect: mance ±0.002% of span per 1V

change

**Over-Voltage Protection:** 

48V maximum on output; 48V reverse polarity protection on

output

**Maximum Input Overrange:** 

Current: 100mA maximum continuous; Voltage on Current Input: ±5Vdc peak; Voltage: 18Vdc

Load Capability:

Supply Voltage -10V = ohms

0.02A

**Output Current Limiting:** 

3.8mA (low) and 21.4mA (high)

**Ambient Operating Range:** Conditions \_40°C to +85°C

(-40°F to +185°F)

Storage Range: -40°C to +85°C

(-40°F to +185°F)

**Effect of Ambient** Temperature on Accuracy:

±0.015% of span/°C

**Ambient Relative Humidity:** Conditions 0-95%, non-condensing

(continued) RFI/EMI Immunity: 20V/m @ 20-1000MHZ, when tested according

to SAMA standard 33.1 (10V/m @ 80-1000MHz, 1k AM, when tested according to IEC

1000-4-3-1995) **Common Mode** 

Rejection: 100dB, minimum, @ 50/60Hz

**Normal Mode Rejection:** 60dB, typical, @ 1V peak-

to-peak, 50/60Hz

Adjustments The choice of a current or

a voltage input is selected via the input terminals; all other settings are made using Windows-based configuration software

Weight HPP-Style housing:

65 g (2.3 oz) **DIN-Style Housing:** 184 g (6.5 oz) LH1-Style Housing: Polyester Cover:

283.5 g (10 oz) Metal Cover: 468 g (16.5 oz)

### **Default Factory Configuration** for SIY

settings for your SIY unit:

Input:

4-20mA

Settings:

Input Trim OFF

Filter:

60Hz

**Output:** 

4-20mA

Damping: 0s

The following are the factory default configuration

Specifications and information subject to change without notice.

### **Ordering Information**

Unit	Input	Output	Power	Options	Housing
SIY PC-Program- mable Isolator/ Converter	PRG Programmable with supplied Configuration Software and front panel connection terminals for:  CURRENT (into 20ohms): Any range from -2.5mA to 55mA including: 0-20mA 4-20mA 0-50mA 10-50mA (recommended minimum span, 1mA)  VOLTAGE (into 1Mohm): Any range from -0.5 to 11V including: 0-5Vdc 1-5Vdc 0-10Vdc (recommended minimum span, 250mV)	4-20mA Programmable output span between 4mA minimum and 20mA maximum into 650ohms with 24Vdc power supply	10-30DC Required	-ISC CSA approved IS (HPP) -ISE LCIE- ATEX approved IS (HPP) -ISF FM approved IS (HPP) -VTD Standard Factory Calibration with NIST Test Data Report	DIN DIN-style aluminum housing mounts on 32mm G-type (EN50035) and 35mm Top Hat (EN50022) rails D2LC‡ D-Box, Low-Base Enclosure with Clear Valox Cover, NEMA 4X, IP66, 2-Hub Connections ½-inch NPT Refer to D-Box data sheet for dimensions D2LS‡ D-Box, Low-Base Enclosure with Solid Valox Cover, NEMA 4X, IP66, 2-Hub Connections ½-inch NPT Refer to D-Box data sheet for dimensions HPP Hockey-puck housing for mounting in standard connection heads  LH1NS‡ Connection head (NEMA 4X, IP66) with two entry ports: ½-inch NPT cable and process—black PBT polyester cover  LH1MS‡ Connection head (NEMA 4X, IP66) with two entry ports: M20 cable and ½-inch NPT process—black PBT polyester cover  LH1CS‡ Connection head with two entry ports: M20 cable and G½ (BSP) process—black PBT polyester cover  LH1NX Connection head with ½-inch NPT entry and mounting plate for customer's air duct opening—black PBT polyester cover  LH2NS* Explosion-proof connection head with two entry ports: ½-inch NPT cable and process—black metal cover  LH2MS* Explosion-proof connection head with two entry ports: M20 cable and ½-inch NPT process—black metal cover  NOTE:  *A suffix with LH2 indicates ANZEx/TestSafe (Ex d) Flame-Proof approval; 2"pipe-mount kit included (i.e., LH2MSA)  *E stiffix with LH2 denotes ATEX Flame-Proof enclosure; 2" pipe-mount kit included (i.e., LH2MSE)  *‡ P suffix indicates enclosure is equipped with 2" pipe-mount hardware kit (i.e., LH1NSP)

When ordering, specify: Unit / Input / Output / Power / Options [Housing]
Model number example: SIY / PRG / 4-20MA / 10-42DC [DIN]



### SIY Model Numbers—Ordering

To order additional or replacement transmitters for your application or system, refer to the Ordering Information table and "build" a model number using the information shown in bold text. Specify the following in order:

### Unit / Input / Output / Power [Housing]

For a SIY in DIN-style housing, specify:

### SIY / PRG / 4-20MA / 10-42DC [DIN]

For a SIY in a *D-BOX* enclosure with two ports and pipe mount hardware, order:

### SIY / PRG / 4-20MA / 10-42DC [D2LSP]

Factory Calibration. To order a SIY factory-calibrated to a specific input range, contact your local Moore Industries Sales Representative. Provide the input range you require in the "Calibration Notes" section of the order. They will be happy to provide you with pricing information.

### **Accessories**

Each shipment of SIY transmitters comes complete with the software needed for configuration. To order programming cables, call your factory Sales Representative for the following part numbers:

- RS232 and USB, Non-Isolated Configuration Cables, P/N 803-040-26 (9-pin serial cable) or P/N 804-030-26 (USB cable). These cables are adequate for the majority of applications where the transmitter will be configured in the shop using a grounded, line-powered PC.
- RS232 Isolated Configuration Cable, P/N 803-039-26. This cable is for in situ field configuring. The cable is equipped with a self-powered input-to-output isolation circuit that protects the PC (typically a laptop or notebook) from possible damage due to high electrical potentials.

### **Configuration & Bench Check**

Configuration of the SIY consists of:

- 1. Checking to verify that the unit ordered is in fact the one received and that it has been correctly calibrated by the factory according to the order.
- 2. Installing the SIY Configuration Software.
- 3. Connecting the SIY to a PC and test setup and using TDYFamily Configuration.EXE to check for correct unit tagging, input type and range settings, and output zero/span

Prior to shipment, our team of skilled technicians subjects every SIY to rigorous testing. Every product Moore Industries manufactures, sells, and services is guaranteed to meet the strict quality standards that our company demands.

Even if a unit has been configured to your specifications by the factory (factory calibration), it is a good idea to perform a bench check. In addition to providing a safe means of uncovering any unit damage that may have occurred during shipping, the procedures afford the user the opportunity of becoming familiar with SIY operation in a testing environment that is separate from the intended process or application.

### Note:

The procedures in this section should be carried out in an environment considered appropriate for the general testing of electronic equipment, rather than in the field. Use a technician's bench or similar. lab-type environment.

### **Installing the Configuration Software**

Refer to Table below for the equipment needed.

- 1. Insert the Moore Industries Interface Solution PC Configuration Software CD into the CD drive of the PC. Access the CD and open the "TRX TRY SDY SIY TDY PC Configuration Software" folder.
- 2. Double-click the installation program located in the folder. Follow the prompts to correctly install the program.

Once the Configuration Program is installed on the PC, the SIY can be connected to equipment to simulate input and monitor output. This makes it easy to create a set of operating parameters, save them to disk, and download them to one or more instruments at a later time.

### Connecting the SIY to the PC

Connect the RS-232 or USB end of the cable to the PC's COM port.

The end with the small 3-pin connector will plug in to the face of the SIY.

See Table below for information on the necessary equipment.

Table 1. Assembling the equipment needed to configure the SIY

Device	Specifications			
Current or Voltage Source	Accurate to 0.05% of span for the intended application			
Power Supply	10-42Vdc, ±10%			
Multimeter (optional)	Accurate to ±0.025%; e.g., HP Model 3478A			
Precision Load Resistor (optional)	Accurate to ±0.025%; e.g., HP Model 3478A			
Personal Computer	Microsoft Windows based PC; 16Mb free RAM; 20MB free disk space on hard drive Microsoft Windows XP, 7, or 10  1 (one) serial port or 1 available USB port (with optional USB cable)			
Moore Industries PC Configuration Software	Version 4.5 or greater, successfully installed to the hard drive			
Communication Cable	Non-Isolating 803-040-26 (9-pin Serial), Isolating 803-039-26 (9-pin serial) 804-030-26 (USB)			



### **Bench Check Setup**

Figure 2 shows a SIY hooked up to the equipment needed to perform the unit configuration, bench check, and output trim. Connect your SIY as shown in the figure and allow approximately 5 minutes for the setup to stabilize.


### Note:

It is possible to run the SIY Configuration program without actually connecting a unit to the PC, but you will be unable to set a custom linearization table.

This makes it easy to devise and download a single configuration to several SIY's.

Save the Configuration File to disk and connect the units in succession, downloading the same file to each.

Figure 2. Setting up the SIY for Configuration/Bench Check




### **Using the PC Configuration:** Overview

Once the software has been installed on your hard disk:

- 1. In Windows choose "TRX/TRY/TDY/SIY/ SDY" from All Programs in the Start menu.
- 2. Figure 3 shows the unit selection screen that appears when the setup program is started and the unit is not properly connected to the PC.

Figure 3. Choosing the SIY Setup



3. Set the values as appropriate for your intended SIY application in the various fields of the Configuration Screen in Figure 5.

### Note:

If you are building a Configuration File without a SIY connected, the "SIY Status" section of the screen will be blank, and the "Communication" indicator will show steady on (as opposed to blinking).

During setup, the SIY tests the availability of COM Ports 1 through 4 in your system. The first available COM port is designated for SIY communications and is noted on the Configuration Screen. Your SIY communications cable must be connected to this port.

To connect the SIY to a port other than the default described above, disconnect the transmitter, then change the default selection with the pull down menu. Next reconnect the SIY communications cable.

4. When the Configuration File shown on the screen has been modified for your intended application, click "Stop" to stop measurement.

Figure 4. Accessing the Programming Functions of the Configuration Software.

<u>S</u> tart	<u>G</u> et Setup	<u>F</u> ile
Prog	<u>O</u> utTrim	Pri <u>n</u> t
<u>I</u> npTrim	<u>L</u> oop Test	<u>E</u> xit

This will cause the "Prog" button to become available. Click "Prog", and the software will download the parameters on the PC into the non-volatile memory of the connected SIY.

Status of the downloading is shown in the upper left corner of the screen. When completed, the program beeps.


### Note:

Changing the settings on the Configuration Screen does not change SIY paramaters until the Configuration File is downloaded to SIY memory as described in Step 4 above.

Any time the SIY settings are changed, the configuration date will change to reflect the date the new settings were entered.



Figure 5. Setting SIY Parameters Using the Configuration Screen



### Saving the SIY Configuration File to Disk

This is an optional procedure. You do not have to save the file to disk in order to download the file into SIY memory. Use this procedure to save information on the configuration of your SIY for downloading into other SIY transmitters, or for record-keeping purposes, etc.

To save the SIY configuration files to disk:

- Click on the "File" button. This brings up an Explorer-like window on the left area of the screen.
- 2. Enter the file name that you wish to save in the "File Name" box, see Figure 6.
- Use the Explorer-like interface to designate the location on the PC drive for the file to be saved.
- 4. Click on "Save"
- Click "Yes" to save the named file to disk. 5.

### **Using a Configuration File** Already on Disk

To download or edit a previously saved Configuration File you can use the "File" button on the SIY Configuration Screen to bring up a file from your hard disk.

To use a configuration file already on disk:

- Click File on the SIY Configuration Screen to bring up the File Operations function of the program.
- 2. Click on Open File and select the file you wish
- 3. When the Configuration File shown on the screen has been modified for your intended application, click "Stop" to stop measurement.

This will cause the "Prog" button to become available. Click "Prog", and the software will download the parameters on the PC into the non-volatile memory of the connected SIY.

Status of the downloading is shown in the upper left corner of the screen. When completed, the program beeps.

Changing the settings on the Configuration Screen DOES NOT CHANGE SIY PARAMETERS until the Configuration File is downloaded to SIY memory.







### Loading a Configuration File from a Connected SIY

To edit or view a Configuration File in the non-volatile memory of a connected unit, you can use the "Get Setup" function of the Configuration program.

Connect a powered SIY to your PC and click the "Get Setup" button in the software. It will transfer all the configuration information from your SIY to the PC Configuration Software screen.

### Setting Output Damping

To lessen the impact of your sensor's step increases and decreases, you may want to set the damping time, which will cause the SIY to average out fluctuations over the set amount of time.

Setting the damping time is simple; simply click on the damping value bar under the "Output" portion of the screen (in the bottom-right corner), or click on the box to the right of the "Damping (sec)" area and type in a number between 0 and 20

### **Trimming SIY Output**

The SIY has a function that allows precise control over its output. Note that to activate this function. a unit must be connected in the setup to current meter, as shown in Figure 2.

### To trim SIY output:

Set all unit parameters on the SIY Configuration Screen as required for your intended application.

> When the Configuration File shown on the screen has been modified for your application, click "Stop" to stop measurement.

- 2. Click "OutputTrim".
- Select and move the "Zero Scale Output" or 3. the "Full Scale Output" slide bar to adjust the SIY output.

Monitor the output with a calibrated current meter or with a voltmeter measuring the drop across a precision, 250 Ohm resistor (see Figure 2).

4. When both zero and full scale have been adjusted to satisfaction, press "QuitTrim", then "Prog" to program the SIY with the new trim values.

### Note:

Changing the settings shown on the screen in "Trim" mode DOES NOT CHANGE THE UNIT'S OPERATING PARAMETERS, it only updates the screen. The settings are saved to non-volatile memory by using the "Prog" function.


The "SIY Status" area of the Configuration Screen will reflect the new output settings being downloaded into unit memory.

### **Trimming the Input**

Use this feature of the SIY to enhance the accuracy of the transmitter by precisely matching its actual reading of the input to its scaling of the either one or two input points. Trim the input by following the directions below:

- 1. Connect the transmitter to your PC using the setup shown in Figure 2.
- 2. Click the radio button labeled "Input Trim On". Then click "Start", and "InputTrim".
- Select whether you will trim two points (upper 4. and lower) or just one point by clicking on the appropriate radio button in the "Trim Pnts" section.
- 5. In the "Trim Lower" and "Trim Upper" boxes, type in the sensor's value that you are trimming.
- 6. Attach an input source to the transmitter. Using a calibrated multimeter to determine the current, set the input source to match the "Trim Lower" value you have chosen. Click "Trim Low" and wait for it to capture the value.
- Using a calibrated multimeter to determine the current, set the input source value to match the "Trim Upper" value you have chosen. Click "Trim Upp" and wait for it to capture the value. Download the new file to the transmitter, and you are done.

Figure 7. Trim Capture Box





### **Creating a Custom Linearization Table**

The SIY supports user-defined linearization of both voltage and current inputs. Up to 85 input/ output points can be defined, and the user can also specify the format and engineering units of the output (viewable with the Configuration Program).


This section explains how to create a Custom Linearization Table for downloading into SIY memory.

The instructions assume that the Configuration Program has been loaded successfully. Moore Industries also suggests saving the initial settings resident in the transmitter before making any changes.

To create a Custom Linearization Table:


- Attach the equipment listed in Table 1 as shown in Figure 2 and start the PC Configuration Program.
- 2. Click the "CustTable" button in the lower-left area of the Configuration Main Screen.

Figure 8. Linearization Must be set to ON to create a Custom



Click on the "CustTable" (Customize 3. Linearization Table) button. This causes the Configuration Program to change its upperright corner area to accommodate the table.

Figure 9. Custom Table Display




Use the table fields to set values for input and output from the transmitter's intended application.

> Use the Up, Down, Left, and Right arrow keys on the PC keyboard to move the cursor among the cells in the table.

- Use the "EGU" field to set the Engineering units of the readout from the transmitter when connected to the Configuration Program.
- Set the "Output Format" field to the desired resolution using the pull-down menu.
- Enter the number of points to use to constitute 7. the Linearization Table in the "Points" field.

8. When the table is complete, click on the "QuitTable" button and answer "Yes" to the following dialog (or something similar)

Figure 10. Save File Dialog Box



Click on the "Prog" (Program) button to download the output trim settings into the transmitter memory.

### **CAUTION:**

Any time a connected SIY is "programmed" by downloading a Configuration File into memory, ALL of the configuration parameters resident in the transmitter memory at the time of the download are OVERWRITTEN.

This includes things like: tag name, calibration date, trim values, etc.

Once a transmitter's memory is "erased" in this fashion, the old operating parameters are unrecoverable, and will have to be regenerated from scratch if needed again.

### The Rules for Custom Linearization:

- The difference between any consecutive values in the table (in either column) must be less than 50% of the entire configured range.
- One "Output EGU" value per "Input mV" value only.
- It is not necessary to use all 85 available points, but the first and last points in the curve always default to the 0% and 100% input scale (input range).
- If you decide not to use all 85 points, you must change the number of points in the "Points" field to the number you wish to use.

### Note:

Moore Industries suggests filling in the EGU (Engineering Units), then the number of points, and finally the values in the table.



### Installation

The SIY transmitter is available in either the HPP hockey-puck housing style or the compact, universal, DIN-style housing.

The HPP housing includes a metal mounting plate secured to the bottom. The case is designed to fit inside the popular 30-35 mm connection head. The DIN-style housing can be mounted on either 32 mm, G-type DIN rail (EN50035), or 35mm, Top Hat rail (EN50022). The DIN-housed unit is also equipped with removable terminal blocks.

Figure 11 shows the dimensions of the HPP housing. The dimensions of the DIN-style SIY are shown in Figure 12.

### **Mounting and Connections**

Moore Industries suggests installing the SIY by first mounting the unit in its intended application, then making the electrical connections to input, output, and power.

Before any installation, make sure that the unit has been bench checked to ensure that it is configured and calibrated for its intended application.

### Mounting the HPP-Housed SIY

Use 4.5mm (0.18 in) screws to connect the SIY and mounting plate to a connection head or other housing.

### Mounting the DIN-Housed SIY

For a Top Hat DIN rail, seat the upper extrusion on the back panel over the top of the rail and pivot downward until the housing locks into place.

For a G-type rail, seat the extrusion under the top lip of the rail and pivot downward.

### Electrical Connections for the HPP-Housed SIY

Figure 13 shows the hookups for the SIY when in their HPP housing configuration. Feed the sensor wiring up through the center thru-hole (and typically, out a side port of the connection head).

### Electrical Connections for the DIN-Housed SIY

Figure 14 shows the hookups for the SIY in DINstyle housing. Refer to the section on ground wiring practices when installing this type of transmitter.

### **Electrical Safety Information**

Refer to the Electrical Safety Manual included at the end of this manual, also available as a separate document.

Figure 11. Dimensions of the HPP version of the SIY





Figure 12. Dimensions of the DIN-Style version of the SIY



### **Operation**

Once programmed, calibrated, installed, and supplied with the correct power, SIY transmitters begin to operate. Depending upon environmental conditions, they can be expected to continue to operate unattended for extended periods of time.

### **Maintenance**

Moore Industries suggests you perform a quick check for terminal tightness and general unit condition every 6-8 months. Always adhere to any site requirements for programmed maintenance.

### **Troubleshooting**

If a transmitter's performance begins to deteriorate noticeably and a physical check of the installation uncovers no adverse conditions or damage, remove the unit from service and perform the calibration procedures listed earlier in this manual. Check in particular the Trim Output procedure.

Figure 13 Connecting the HPP-Housed SIY





Figure 14. Connecting the DIN-Housed SIY



### **Customer Support**

Moore Industries is recognized as the industry leader in delivering top quality to its customers in products and services. We perform a battery of stringent quality assurance checks on every unit we ship. If any Moore Industries product fails to perform up to rated specifications, call us for help. Our highly skilled staff of trained technicians and engineers pride themselves on their ability to provide timely, accurate, and practical answers to your process instrumentation questions. Factory phone numbers are on the back cover.

If problems involve a particular SIY, there are several pieces of information you can gather before you call the factory that will help our staff get you answers more efficiently. When you call, please have:

- The model number of the unit in question.
- The serial number of the unit in question.
- The job number (if available).
- The purchase order under which the unit was shipped (if available).

### **RETURN PROCEDURES**

To return equipment to Moore Industries for repair, follow these four steps:

1. Call Moore Industries and request a Returned Material Authorization (RMA) number.

### Warranty Repair -

If you are unsure if your unit is still under warranty, we can use the unit's serial number to verify the warranty status for you over the phone. Be sure to include the RMA number on all documentation.

### Non-Warranty Repair -

If your unit is out of warranty, be prepared to give us a Purchase Order number when you call. In most cases, we will be able to quote you the repair costs at that time. The repair price you are quoted will be a "Not To Exceed" price, which means that the actual repair costs may be less than the quote. Be sure to include the RMA number on all documentation.

- 2. Provide us with the following documentation:
  - a) A note listing the symptoms that indicate the unit needs repair
  - b) Complete shipping information for return of the equipment after repair
  - c) The name and phone number of the person to contact if questions arise at the factory
- Use sufficient packing material and carefully pack the equipment in a sturdy shipping container.
- 4. Ship the equipment to the Moore Industries location nearest you.

The returned equipment will be inspected and tested at the factory. A Moore Industries representative will contact the person designated on your documentation if more information is needed.

The repaired equipment, or its replacement, will be returned to you in accordance with the shipping instructions furnished in your documentation.

### **WARRANTY DISCLAIMER**

THE COMPANY MAKES NO EXPRESS, IMPLIED OR STATUTORY WARRANTIES (INCLUDING ANY WARRANTY OF MERCHANTABILITY OR OF
FITNESS FOR A PARTICULAR PURPOSE) WITH RESPECT TO ANY GOODS
OR SERVICES SOLD BY THE COMPANY. THE COMPANY DISCLAIMS ALL
WARRANTIES ARISING FROM ANY COURSE OF DEALING OR TRADE
USAGE, AND ANY BUYER OF GOODS OR SERVICES FROM THE COMPANY ACKNOWLEDGES THAT THERE ARE NO WARRANTIES IMPLIED
BY CUSTOM OR USAGE IN THE TRADE OF THE BUYER AND OF THE
COMPANY, AND THAT ANY PRIOR DEALINGS OF THE BUYER WITH THE
COMPANY DO NOT IMPLY THAT THE COMPANY WARRANTS THE GOODS
OR SERVICES IN ANY WAY.

ANY BUYER OF GOODS OR SERVICES FROM THE COMPANY AGREES WITH THE COMPANY THAT THE SOLE AND EXCLUSIVE REMEDIES FOR BREACH OF ANY WARRANTY CONCERNING THE GOODS OR SERVICES SHALL BE FOR THE COMPANY, AT ITS OPTION, TO REPAIR OR REPLACE THE GOODS OR SERVICES OR REFUND THE PURCHASE PRICE. THE COMPANY SHALL IN NO EVENT BE LIABLE FOR ANY CONSEQUENTIAL OR INCIDENTAL DAMAGES EVEN IF THE COMPANY FAILS IN ANY ATTEMPT TO REMEDY DEFECTS IN THE GOODS OR SERVICES, BUT IN SUCH CASE THE BUYER SHALL BE ENTITLED TO NO MORE THAN A REFUND OF ALL MONIES PAID TO THE COMPANY BY THE BUYER FOR PURCHASE OF THE GOODS OR SERVICES.

ANY CAUSE OF ACTION FOR BREACH OF ANY WARRANTY BY THE COMPANY SHALL BE BARRED UNLESS THE COMPANY RECEIVES FROM THE BUYER A WRITTEN NOTICE OF THE ALLEGED DEFECT OR BREACH WITHIN TEN DAYS FROM THE EARLIEST DATE ON WHICH THE BUYER COULD REASONABLY HAVE DISCOVERED THE ALLEGED DEFECT OR BREACH, AND NO ACTION FOR THE BREACH OF ANY WARRANTY SHALL BE COMMENCED BY THE BUYER ANY LATER THAN TWELVE MONTHS FROM THE EARLIEST DATE ON WHICH THE BUYER COULD REASONABLY HAVE DISCOVERED THE ALLEGED DEFECT OR RRFACH.

### RETURN POLICY

For a period of thirty-six (36) months from the date of shipment, and under normal conditions of use and service, Moore Industries ("The Company") will at its option replace, repair or refund the purchase price for any of its manufactured products found, upon return to the Company (transportation charges prepaid and otherwise in accordance with the return procedures established by The Company), to be defective in material or workmanship. This policy extends to the original Buyer only and not to Buyer's customers or the users of Buyer's products, unless Buyer is an engineering contractor in which case the policy shall extend to Buyer's immediate customer only. This policy shall not apply if the product has been subject to alteration, misuse, accident, neglect or improper application, installation, or operation. THE COMPANY SHALL IN NO EVENT BE LIABLE FOR ANY INCIDENTAL OR CONSEQUENTIAL DAMAGES.



WORLDWIDE • www.miinet.com

United States • info@miinet.com
Tel: (818) 894-7111 • FAX: (818) 891-2816
Australia • sales@mooreind.com.au
Tel: (02) 8536-7200 • FAX: (02) 9525-7296

Belgium • info@mooreind.be Tel: 03/448.10.18 • FAX: 03/440.17.97 The Netherlands • sales@mooreind.nl Tel: (0)344-617971 • FAX: (0)344-615920 China • sales@mooreind.sh.cn
Tel: 86-21-62491499 • FAX: 86-21-62490635
United Kingdom • sales@mooreind.com
Tel: 01293 514488 • FAX: 01293 536852



### SIY ELECTRICAL SAFETY MANUAL

**July 2020** 235-731-09A

### **Electrical Safety Manual**

This document allows the user quick access to all electrical information for the purpose of safety installation in a specific area. The Electrical Safety Manual does not replace the full manual that is included with the unit; refer to the full manual for additional details on specification, unit configuration, customer service, warranty, and more.

### **Safety Messages**

All Moore Industries instrumentation should only be used for the purpose and in the manner described in both manuals. If you use this product in a manner other than that for which it was intended, unpredictable behavior could ensue with possible hazardous consequences.

### **Qualified Personnel**

The Moore Industries' product/systems described in the manuals may be operated only by personnel qualified for the specific task in accordance with the relevant documentation, in particular its warning notices and safety instructions. Qualified personnel are those who, based on their training and experience, are capable of identifying risks and avoiding potential hazards when working with these Moore Industries' products/systems.

### **Proper Use of Moore Industries Products**

Moore Industries' products may only be used for the applications described in the catalog and in the relevant technical documentation. If products and components from other manufacturers are used, these must be recommended or approved by Moore Industries'. Proper transport, storage, installation, assembly, commissioning, operation and maintenance are required to ensure that the products operate safely and without any problems. The permissible ambient conditions must be complied with. The information in the relevant documentation must be observed.

### World Headquarters

16650 Schoenborn Street North Hills, California 91343-6196, U.S.A. Tel: (818) 894-7111 Fax: (818) 891-2816

E-mail: info@miinet.com TOLL FREE: 1-800-999-2900

www.miinet.com

### Installation and Wiring

Instructions in this section and others may require special precautions to ensure the safety of the personnel performing the operations. Notes, Cautions and Warnings that may cause potential safety issues are indicated throughout this guide.

**Note:** Make sure to calibrate and bench check the instruments prior to installation. Also, install all instruments in their intended application before making any electrical connections. For DIN rail mounted instruments, allow enough room for pivoting instruments vertically on the rail for removal in applications involving multiple banks of units. To remove the unit from the DIN rail you will need a simple tool such as a straight blade screwdriver. Insert the blade of the screwdriver into the cavity at the bottom of the locking mechanism and rotate it. This will release the locking mechanism from the DIN rail and allow you to remove the unit.

Moore Industries suggests installing by first mounting the unit in its intended application, then making the electrical connections to input, output, and power.

The HPP housing includes a metal mounting plate secured to the bottom. The case is designed to fit inside the popular 30-35 mm connection head. The DIN-style housing can be mounted on either 32 mm, G-type DIN rail (EN50035), or 35mm, Top Hat rail (EN50022). The DIN-housed unit is also equipped with removable terminal blocks.

### **Electrical Connections**

When installing any Moore Industries product, always follow all local regulations and standards for grounding, shielding, and safety. Use +90°C suitable wiring for all connections.

WARNING: Terminals on this unit may be connected to hazardous voltages. Before making ANY connections to this unit, always remove power from the loop or instrument power terminals.

WARNING: If this unit is used in a manner not specified by Moore Industries, the protection provided by the equipment may be impaired.

### Input/Output Wiring

The input/output connections can be made with 14 to 24 AWG (2.5mm<sup>2</sup> to 0.2mm<sup>2</sup>) wire. The end of each conductor should be stripped no more than 0.25in (7mm). Tighten the screws on the terminal block to 4.4 - 5.3 lbf/in<sup>2</sup> (0.5 - 0.6 N/m<sup>2</sup>).

Power Supply Wiring All power connections should be made with 14 or 16 AWG (2mm $^2$  or 1.3mm<sup>2</sup>) wire. The end of each conductor should be stripped no more than 0.25in (7mm). The end of the stripped wire should be tinned with solder, or inserted into a ferrule and crimped before being placed into a terminal block. Tighten the screws on the terminal block to 4.4 - 5.3  $lbf/in^2$  (0.5 - 0.6 N/m<sup>2</sup>).

### **Recommended Ground Wiring Practices**

Moore Industries recommends the following ground wiring practices:

- · Any Moore Industries product in a metal case or housing should be
- The protective earth conductor must be connected to a system safety earth ground before making other connections.
- · All input signals to, and output signals from, Moore Industries' products should be wired using a shielded, twisted pair wiring technique. Shields should be connected to an earth or safety ground.
- For the best shielding, the shield should be run all the way from the signal source to the receiving device. (see Note below)
- · The maximum length of un-shielded input and output signal wiring should be 2 inches.

Note: Some of Moore Industries' instruments can be classified as receivers (IPT2, IPX2, etc.) and some can be classified as transmitters (TRX, TRY, etc.) while some are both a receiver and a transmitter (SPA2, HIM, etc). Hence, your shield ground connections should be appropriate for the type of signal line being shielded. The shield should be grounded at the receiver and not at the signal source.

### **CE Certification-related Guidelines**

The grounding and wiring practices described above must be followed in order for the unit(s) to meet the requirements set forth in EMC standard EN 61326.

## Model Structure EXAMPLE SIY / PRG / 4-20MA / 10-30DC / -ISE [HPP] Unit Type Unit Type Input Output Power Options Housing

### **Specifications**

### Supply Voltage:

<u>Standard Nominal:</u> 10-42Vdc, 24mA max. Intrinsically Safe:

Ui = 30Vdc, Ii = 110mA, Pi = 825mW

Terminals: Rated CAT I
Operating & Storage Range:
-40°C to +85°C (-40°F to +185°F)

### **Installation in Hazardous Locations**

This section contains important information regarding installation of SIY in Hazardous Area Locations.

<u>Note:</u> The SIY-DIN is suitable for use in Non-Hazardous locations only. See cCSAus installations.

**WARNING:** Do not separate power connector when energized.

<u>WARNING:</u> Substitution of components is not allowed, as it may impair the intrinsic safety.

<u>AVERTISSEMENT:</u> La substitution de composants peut compromettre la sécurité intrinséque.

<u>WARNING:</u> To prevent ignition of flammable or combustible atmospheres, disconnect power before servicing.

<u>AVERTISSEMENT:</u> Risque d'explosion. Avant de déconnecter l'equipement, couper le courant ou s'assurer que débrancher tant que l'emplacement est désigné non dangereux.

<u>WARNING:</u> Explosion Hazard. Do not disconnect equipment when a flammable or combustible atmosphere is present.

<u>AVERTISSEMENT:</u> Risque d'explosion. Ne pas débrancher tant que le circuit est sous tension, a moins qu'il ne s' agisse d'un emplacement non dangereux.

<u>WARNING:</u> Explosion Hazard. Substitution of components may impair suitability for Class I, Division 2.

<u>AVERTISSEMENT:</u> Risque d'explosion. La substitution de composants peut rende ce materiel inacceptable pour les emplacements de Classe I, Division 2

Maximum operating parameters of the "COM" port for use in Non-Hazardous areas shall not exceed 3.0V,  $300\mu A$  and  $240\mu W$ .

### **Specific Conditions of Use**

The following instructions must be adhered to when the SIY is used in hazardous locations and potentially explosive atmospheres.

FM Installations
Intrinsically Safe Applications
Class I, Division 1, Groups A, B, C & D T6
Class I, Zone 0, AEX ia IIC T6 Ga
Nonincendive Applications
Class I, Division 2, Groups A, B, C & D T6
Operating Ambient Temperature Range:
-40 °C ≤ Tamb. ≤ +60°C

When installed as Division 1 or Zone 0 equipment, install per I.S. Control Drawing 100-100-60.

The SIY shall be mounted within a tool-secured enclosure which meets the requirements of ANSI/UL 61010-1 and is capable of accepting applicable wiring methods per the NEC\*. The enclosure shall have a minimum type of protection IP20, but shall have a suitable degree of protection against deterioration of the equipment that would adversely affect its suitability for use in Class I, Division 1, Zone 0 or Division 2 locations.

No connections shall be made to the communications "COM" port in Hazardous (Classified) Locations.

Programming through the communication port shall only be done in the unclassified location using the Moore Industries USB cable, Part No. 804-030-26.

CSA Installations
Intrinsically Safe Applications
Class I, Division 1, Groups A-D T6@60°C ambient
Nonincendive Applications
Class I, Division 2, Groups A-D T6@60°C ambient

The SIY is of open type unit Certified as a component for use only in other equipment where the suitability of the combination is to be determined by the authority having jurisdiction.

European Union Installations (ATEX 2014/34/EU) Intrinsically Safe Applications II 2 G EEx ib IIC

The model SIY is intrinsically safe. It can be used in potentially explosive atmospheres and can only be connected to certified intrinsically safe associated equipment. This combination must be compatible with regards to intrinsic safety.

The specific electrical parameters of the SIY are:

Terminals +ps -ps: Ui<= 30V; Ii <= 110mA; Pi<= 0.82W; Ci <= 50.2nF; Li = 0 Terminals 1,2,3,4: Uo <= 6.5V; Io <= 110mA, Po <= 0.82W; Co <= 2.96uF; Lo <= 2.9mH

The electrical parameters of the certified associated intrinsically safe equipment must not exceed any of the following values:

Terminals +ps -ps: Uo <= 30V; lo <= 110mA; Po<= 0.82W

The "COM" port must not be used in hazardous areas.


The operating ambient temperature must be between -40° C and 60° C

### cCSAus Installations General Locations


The equipment is certified only for use in other equipment where the suitability of the combination is to be determined.

### **Connection Diagrams**

Connecting the HPP-Housed SIY



### Connecting the DIN-Housed SIY







## Field Installation Diagram: SIY [HPP]

CONTROL DRAWING

CATEGORY

PC-Prog. Signal Isolator/Converter Intrinsically Safe System For Hazardous "Classified" Locations

100-100-60 ECO 18886

REVISED BY


DRAWING NUMBER


36  $\begin{vmatrix} DATE & BY \\ 07/20 & T.G. \end{vmatrix}$ 

W.T.

REVISION

NOTICE RE PROPRIETARY INFORMATION: This drawing and the information contained herein are the proprietary property of Moore Industries International, Inc. (MII) and should not be reproduced or disclosed to any third party without the written consent of an authorized officer of MII.





 $V_{OC}$  or  $V_t = 6.51 \text{ Vdc}$ 

 $C_a$  or  $C_o = 10 \mu F$  $L_a$  or  $L_o = 2.7 mH$ 

mA, mV, V:

 $I_{SC}$  or  $I_t = 110 \text{ mA}$ 

 $P_0 = 0.560 W$ 

Communication Cable

တ

Moore Industries

Unspecified

Linear Output Associated Apparatus

Apparatus

\_

2

3 tps

<del>-</del>PS

# Entity Parameters (Power/Loop, +PS & -PS): $V_{max}$ or $U_i = 30 \text{ Vdc}$ $I_{max}$ or $I_i = 110 \text{ mA}$ $P_{max}$ or $P_i = 0.825 \text{ W}$ $C_i = 10.34 \text{ nF}$ $L_i = 0 \text{ µH}$ $C_a$ or $C_o \geq C_i + C_{cable}$ $L_a$ or $L_o \geq L_i + L_{cable}$ $V_{max}$ or $U_i \geq V_{oc}$ or $V_t$ $I_{max}$ or $I_i \geq I_{sc}$ or $I_t$ $P_i \geq P_c$

Input Device must be 'Agency' approved per application area (CSA, FM, ISSeP, LCIE, etc...)

# Ground/Earth Path Resistance Must Not Exceed 1 Ω (Barrier must be Agency approved)

# AREA CLASSIFICATION TRating FM US & Intrinsically Safe: Class I, Division 1, Groups A, B, C & D CSA International Non-Incendive: Class I, Division 2, Groups A, B, C & D FM (US NEC 500) Intrinsically Safe: Class I, Zone 0, AEx ia IIC LCIE/ATEX Intrinsically Safe: ⑤ II 2G EEx ib IIC T. Code: T6 ⊚ 60°C Maximum Operating Ambient Temperature Range: -40°C ≤ Tamb. ≤ +60°C

## Installation Notes:

- Associated apparatus which is unspecified except that it must not be supplied from, or contain under normal or abnormal conditions a source of potential with respect to earth in excess of 250 Vrms or 250 Vdc which is considered to be the Safe Area's maximum voltage.
- 2 must be installed per the manufacturer's guidelines. A Shunt Zener Barrier is NOT required for Non-Incendive (or Class I, Division 2 or Type N) installations or "Zone 0" locations. The output voltage ( $V_{oc}$ ,  $V_t$  or  $U_o$ ) must not exceed 30 Vdc, the output current ( $I_{sc}$ ,  $I_t$  or  $I_o$ ) must not exceed 110 mA and, the output power ( $P_o$ ) must not exceed 0.825W ( $P_i$ ). Also, it The Linear Output Associated Apparatus must be approved by the "specific" (CSA/EECS/FM/LCIE/SAA/SIRA/TUV, etc..) certifying agency for I.S. connections in: "Class I, Division 1, Groups A, B, C & D"
- ω 4. The combined Capacitance and Inductance of the inter-connecting cables and the PC Prog. Transmitters must not exceed the values indicated on the Associated Apparatus.
- applications, adhere to the "Canadian Electric Code C22.1' most current publication on I.S. installation guidelines. For ATEX applications, adhere to 'EN 60079-14:1997' or any equivalent, most current and For FM applications, installation must be in accordance to "ANSI/ISA-RP12.06.01" (Installation of I.S. Systems for Hazardous "Classified" Locations) and the National Electric Code 'ANSI/IFPA 70' For CSA pertaining publication on I.S. installation guidelines.
- Ö servicing. Also read, understand and adhere to the manufacturer's installation and operating procedures. Warning: Substitution of components may impair the Intrinsic Safety of the unit. DO NOT open or service the unit when either energized or if an explosive gas/dust atmosphere is present. Disconnect power
- <u></u> "COM" port in Hazardous (Classified) Locations. Programming through the communication port shall only be done in the unclassified location using the Moore Industries USB cable, Part No. 804-030-26 The maximum power parameters of the COM port (to be used only in safe/non-hazardous areas) are: Vmax = 3.0 Vdc, Imax = 300uA, Pmax = 240uW. No connections shall be made to the communications