



May 1999 Data Sheet 5.60

## Description

Moore Industries' instrument air filters eliminate problems in pneumatic instruments caused by oil, condensible liquids and particulates that are often present in process plant instrument air supplies.

Available filters are designed for use with a wide range of pneumatic instruments—such as Moore Industries' IPT and IPF Current-to-Pressure Transmitters—and for both single and multiple unit applications. This includes pneumatic instruments installed in racks, cabinets, and other multiple unit enclosures. Moore Industries offers two levels of instrument air filters.


**The 5-Micron Filter** is for service in normal environments using instrument grade air. This filter removes bulk liquids and reduces particulates down to 5 microns.

**The Coalescing Filter** removes condensible liquids as well as particulate materials. It provides assured clean, dry air in even the most severe environments.

Ensure instrument reliability, reduce maintenance and increase product life with Moore Industries' air filters. They exceed ISA air quality requirements for instrument grade air.

Table 1. ISA Air Quality Requirements for Instrument Grade Air (ISA-S73, 1975; ANSI MC11.1 - 1975)

Condition	Requirements			
Dew Point	Outdoor installations: Must be at least 8°C (18°F) below the minimum local ambient temperature.  Indoor Installations: Must be at least 8°C below the minimum temperature, or +2°C (35°F), whichever is greater.			
Particle Size	Maximum particle size allowed is 3 microns.			
Oil Content	Maximum total oil or hydrocarbon content of condensible products should be as close to zero as possible, but in no circumstances should they exceed 1 PPM W.W or VN under normal conditions.			



Moore Industries' offers a wide range of instrument air filters ideal for single- and multiple-unit applications.

## **Features**

- Service life indicators. All coalescing filters have a color-coded service life indicator which visually shows when the filter element needs changing.
- Automatic drains. Eliminate the need to manually drain filters. This reduces maintenance requirements and makes them ideal for use in inaccessable areas.
- Metal bowls. Provide maximum strength, service life and chemical resistance.
- Pyrex sight glasses. Allow easy visual checking of filter liquid levels.



# **Specifications**

Maximum Conditions

250 psig (17.2 bar); 175°F Rated (79°C); (for 800-801-43, Operating 0 to 150°F / -18 to 66°C).

Fluid Compressed air.

Drain Automatic with 1/8" NPTF connection (800-801-43 has 1/4" ID flexible tubing protrusion on bottom of bowl). Manual drain is optional.

Filter 5-Micron Filter: Removes Element bulk liquids and solids down to 5 microns.

Coalescing Filter:

Removes over 99.999% of particles down to 0.01 micron size by D.O.P. test; maximum oil content remaining is 0.01 PPM @ 70°F (21°C).

Bowl Metal with sight glass.\*

Service Life (Coalescing Filters Only): Indicator

Rotating ball shows green Color Code side when element is new; more red than green indicates element should

be replaced.

Maximum For Efficient Operation Pressure Across 5-Micron Filter: Drop 15psig (1bar).

Across Coalescing Filter:

10 psig (0.7 bar).

Flow Rate

Maximum Refer to Table 2.

Port Size Refer to Table 2.

ment Filter **Elements** 

Replace- Refer to Table 3.

Construction Body: zinc

Materials of 5-Micron Filters

Bowl: zinc w/pyrex sight

Element: polypropylene Elastomers: neoprene,

Coalescing Filters Body: 1" Port: aluminum All others: zinc. Bowl:\* 1" Port: aluminum w/pyrex sight glass.

All others: zinc w/pyrex sight glass.

Element: synthetic fiber & polyurethane foam **Elastomers**: neoprene,

nitrile

Weight Refer to Table 3.

## Ordering Specifications

To order filters, order from Tables 2 and 3 and from tables in Figures 1 and 2.

## Filter Selection

Filter selection is based on the capacity requirements of the system (i.e., the number of IPT or IPF Current-to-Pressure Transmitters to be protected). filter combinations offered by Moore Industries for various IPT/IPF installations are listed in Table 2 on right page. To select the appropriate filter assemblies, first determine the maximum number of units required for the application; then follow the respective row across the table and select the appropriate filter combination.

Combined filter/regulator unit also available. A

unit that combines both a coalescing filter and a miniature supply line regulator is also offered by Moore Industries (Model #800-801-43) for use in low flow, compressed air applications that require regulated, high quality air virtually free of oil aerosols. This space-saving unit has 1/4-inch NPT

female ports and a 4 SCFM maximum flow at 90 psig inlet pressure. It also comes furnished with an integrally mounted pressure gauge that reads in both psi (0-60) and bars (0-4).

#### Replacement Filter Elements

Filter elements must be replaced periodically. A service life indicator on the filter indicates when the element should be replaced. Refer to Table 3 for a complete listing of ordering part numbers for replacement filter elements.

## Installation

Installation dimensions for filter assemblies are presented in Figures 1 and 2 (on right and back page). Wall mounting brackets are also available.

<sup>\* 800-801-43</sup> has a zinc bowl without pyrex sight glass; plus acetal bonnet and brass valve; no manual drain available.

Table 2. Recommended Filter Combinations for IPT and IPF Transmitters\*

Max.	5-Mic	ron Filter		Coalescing Filter			
No. of Units	Ordering Part Number	Port Size, Female NPT (In.)	Max. Flow @ 100 psig (SCFM)	Ordering Part Number	Port Size, Female NPT (In.)	Max. Flow @ 100 psig (SCFM)	
2	800-802-43**	1/4	18	800-806-43** ††	1/4	4	
10	800-803-43	1/4	50	800-824-43	1/4	15	
17	800-804-43	1/2	70	800-826-43	1/2	35	
30	800-804-43	1/2	70	800-809-43	1/2	60	
62	800-805-43	1	445	800-810-43	1	125	

<sup>\*</sup>All filters are based on maximum (full) air flow from the transmitter.


\*\* These filters do not have sight glasses on the bowls.

†Use 800-805-43 with reducing bushing.

Table 3. Replacement Filter Elements and Approximate Weights

Existing Filter Element (P/N)	Weight	Replacement Filter Element (P/N)	Weight
800-801-43*	10 oz.	800-812-43	1 oz.
800-802-43	1 lb.	800-813-43	3 oz.
800-803-43	3 lbs.	800-814-43	5 oz.
800-804-43	3 lbs.	800-814-43	5 oz.
800-805-43	4 lbs.	800-815-43	5 oz.
800-806-43	1 lb.	800-812-43	1 oz.
800-824-43	4 lbs.	800-825-43	8 oz.
800-826-43	4 lbs.	800-827-43	8 oz.
800-809-43	4 lbs.	800-818-43	8 oz.
800-810-43	5 lbs.	800-819-43	8 oz.

<sup>\*</sup>This is a combination filter/regulator. To rebuild regulator portion, order 800-811-43 rebuild kit.



**Typical Unit** (Model 800-805-43 shown)

1. Install vertically (as shown).


NOTE

Figure 1. Installation Dimensions for 5-Micron Filters

	Dimensions: mm (in.)				
Filter Unit	А	B Max. Dia.	С	D	
800-802-43	42	39	10	97	
	(1.63)	(1.53)	(0.38)	(3.81)	
800-803-43	70	77	18	145	
	(2.75)	(2.86)	(0.69)	(5.70)	
800-804-43	70	77	18	145	
	(2.75)	(2.86)	(0.69)	(5.70)	
800-805-43	121	140	32	256	
	(4.75)	(5.52)	(1.25)	(10.06)	

<sup>††</sup>For a combined coalescing filter/regulator unit with gauge for use in low flow compressed air applications that require regulated, high quality air virtually free of oil aerosols, order 800-801-43. Gauge reads in both psi (0–60) and bars (0–4).






Typical Unit (shown with Model 800-808-43)

NOTE

1. Install vertically (as shown).

Figure 2. Installation Dimensions for Coalescing Filters

	Dimensions: mm (in.)					
Filter Unit	А	B Max. Dia.	С	D		
800-806-43	42	39	10	97		
	(1.63)	(1.53)	(0.38)	(3.81)		
800-807-43	99	89	17	160		
	(3.91)	(3.50)	(0.67)	(6.31)		
800-808-43	99	89	17	160		
	(3.91)	(3.50)	(0.67)	(6.31)		
800-809-43	99	89	17	208		
	(3.91)	(3.50)	(0.67)	(8.21)		
800-810-43	121	140	32	256		
	(4.75)	(5.52)	(1.25)	(10.06)		



#### NOTES

- 1. Gage comes unassembled to allow flow left to right or right to left.
- 2. Install vertically (as shown).

Figure 3. Filter Regulator with Gauge: Model 800-801-43



 The Interface Solution Experts • www.miinet.com -United States • info@miinet.com Tel: (818) 894-7111 • FAX: (818) 891-2816 Australia • sales@mooreind.com.au

Belgium • mii.belgium@pandora.be Tel: 03/448.10.18 • FAX: 03/440.17.97 The Netherlands • sales@mooreind.demon.nl

Tel: (0)344-617971 • FAX: (0)344-615920

China · sales@mooreind.com.cn Tel: 86-21-58313053 • FAX: 86-21-68752927 United Kingdom • sales@mooreind.com Tel: 01293 514488 • FAX: 01293 536852